

GENUS USB

PROFESSIONAL UC
HEADSET USER GUIDE



GENUS USB

ADJUSTING THE HEADSET

Place the headset receiver to your ear(s), if using a single ear headset you should set the T-bar above your other ear. Adjust the headset until comfortable, ideally ensuring there is virtually no pressure felt on the ears.

Most headsets can be worn on either ear. To change the microphone side, rotate the microphone boom 180 degrees to the other side.

USING THE QUICK DISCONNECT

Your headset is equipped with a Quick Disconnect lead, allowing you to walk away from your desk without removing your headset.

Before using your headset, ensure the two connectors of the Quick Disconnect lead are joined.

To unplug your headset, grasp either side of the Quick Disconnect and firmly pull apart.

ADJUSTING THE MICROPHONE BOOM

The swing boom can rotate through 330 degrees. To avoid low or distorted sound, and provide clear and crisp telephone call, the microphone should be positioned within 2cms of your mouth.

The microphone boom arm will move in a variety of directions to ensure a best fit.


Do not rotate the boom beyond 330 degrees.

ADJUSTING THE CLOTHING CLIP

A clothing clip to allow comfortable fitting of your headset without the cable getting caught or inadvertently pulled.

The clothing clip should be fastened at a comfortable level, ensuring there is sufficient slack on the cable allowing free movement of your head without disturbing the headset position.

USB CABLE



FUNCTION

1. In-line microphone mute: press the mute button to activate mute, press again to de-activate mute.
2. Microphone mute LED indicator (red)
3. In-line speaker volume controller: press “+” to increase speaker volume, press “-” to decrease speaker volume.
4. In-line hook for answer/end call: press the button to answer the call, press again to end the call
5. Hook LED indicator (green).

SET-UP

- Connect the USB adaptor into any USB port on the computer.
- This cable is plug and play - does not require software install.

NOTE

- Install Skypeheadset™ on you PC to use HOOK function on Skype. Contact your supplier to get the Skypeheadset™ installation file.



Do not use headphones/headsets at high volumes or for an extended period of time. Doing so can cause hearing loss. Always listen at moderate levels.

Do not continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way. Disconnect from your telephone equipment and consult your dealer.

Do not allow electrical equipment to be exposed to rain or moisture.

Do not open the headset housings as doing so will void your warranty.

2 YEAR WARRANTY

There is a two (2) year warranty on this product. We strongly advise you to keep your receipt of purchase in order to prove the date of purchase of this product.

