

ALZO TENT KIT ASSEMBLY

The ALZO 300 "COOL LITE" Tent kit with 3 lights consists of 2 light stands, a Micro-Boom, Mini-clamp and 3 ALZO 300 lights. The larger light stand supports the Micro-Boom with an overhead light and the mini-clamp holds a side light. This is a suggested configuration but many other configurations of the equipment are possible. The Micro-Boom can be used to position a light on the side, top or back of the tent.

We do not recommend using the ALZO 300 fabric diffusers with the tent as this "double diffusion" will greatly reduce the light intensity.



STEP 1: PREPARE LIGHT STAND

The large light stand is supplied with a universal light mount stud that must be removed to install the Micro-Boom. We suggest that you save this item to allow you to use the stand to support a light fixture without the boom.

Fully open the legs of the large light stand and tighten the wing lock screw on the base collar to stabilize the stand.

Back out the wing lock screw until it is almost completely out of the stand top.

STEP 2: ATTACH MICRO-BOOM

Slide the Micro-Boom arm into the top of the large light stand as shown and tighten the wing lock screw on the stand top to hold the bar in place. Then secure the counter weight on the end of the boom with the mounting screw. Loosen the wing lock screw and slide the Micro-Boom to balance it. Re-tighten the wing bolt.

Position the light stand with Micro-Boom either on the front side or back

side of the tent. Raise the top section of the stand such that the tip of the Micro boom is 1 foot above the top of the tent.



AKCES MEDIA LLC 76 Stony Hill Rd, Bethel, CT 06801 800-582-7009 Email - csupport@alzodigital.com http://alzodigital.com

Light Mount Stud



STEP 3: MICRO-BOOM

Secure the ALZO 300 light head to the end of the boom and then re-balance the Micro-Boom. Tighten the wing lock screws and "dress" the power cord along the boom and stand.

Re-positioning of the Micro-boom and setting the wing lock screw will mar the finish of the micro-boom arm and this is typical.



STEP 4: ATTACH THE SIDE LIGHT

Attach the side light to the Micro-Boom stand with the Mini-Clamp as shown here.



FOR ADDITIONAL ASSEMBLY AND USAGE INFORMATION VIST OUR WEB PAGE http://alzodigital.com/customer_support/assembly_guides.htm

