Tri Hawk

Automatic 3 Hands Day Date

SETTING THE TIME

- 1) Unscrew and pull out the crown to the second click position.
- Turn the crown to set hour and minute hands.
 (Check that AM / PM is set correctly)
- 3) Push and screw the crown back into the normal position.

SETTING THE DATE

- 1) Unscrew and pull out the crown to the first click position.
- 2) Turn the crown to left for date setting.
- 3) Turn the crown to right for day setting.
- 4) Push and screw the crown back into the normal position.

Important

- -For long life of the automatic movement, you must rotate the hands clockwise only while adjusting time and date.
- -Correction of the date at every passing midnight.
- -NEVER do any adjustment / setting between 9 pm to 4 am.
- * This watch MUST be worn for at least 8 (Eight) hours each day to ensure it is fully wound. An automatic watch will only wind when the watch is on your wrist and your arm moves. Winding the watch by the crown will put power on the movement but not enough to allow the watch to function fully. If your watch stops overnight or loses time it means it is not being fully wound.



