


CAUTION

Only a light pressure on the lever (A) is required to "set" the gripper firmly on the material.

Undue pressure on the lever may damage the gripper.

The gripper may be turned to any desired position after clamping it to the table.



THE SINGER MANUFACTURING COMPANY

Copyright, U. S. A., 1935 and 1941, by The Singer Manufacturing Co.

Form 18875 (Rev. 441)

All Rights Reserved for All Countries

PRINTED IN U. S. A.