

ColorFit Mighty UM - 84 x 84 mm

<p>ColorFit Mighty</p> <p>Please refer to this manual before using the product</p>	<p>TABLE OF CONTENT</p> <ul style="list-style-type: none"> • What's in the Box • Watch Overview • Charge the Watch • Turn the Watch on and off • Watch Navigation • -Button • -Home Screen Navigation • Setup • -App Setup • -Pair the Watch • General Device Information and Tips • Regulatory Information • Disposal and Recycling Information • Maintenance Instructions • Safety Instructions • Customer Support <p>User Manual for ColorFit Mighty</p>	<p>WATCH OVERVIEW</p> <ul style="list-style-type: none"> • Workout • Workout Record • Activity • Heart Rate • SpO2 • Sleep • Breathe • Call • Favorite Contacts • Alarm • Weather • Stopwatch • Timer • Music Control • Camera Remote • Find My Phone • Flashlight • Settings <p>User Manual for ColorFit Mighty</p>	<p>PACKAGE CONTAINS</p> <p>ColorFit Mighty Smartwatch x 1</p> <p>Charging Cable x 1</p> <p>User Manual for ColorFit Mighty</p>	<p>CHARGING COLORFIT MIGHTY SMARTWATCH</p> <p>Before using your ColorFit Mighty for the first time, charge the battery to its full capacity. Use the charging cable provided with the watch to charge. On a full charge, ColorFit Mighty can last up to 7 days.</p> <p>Note: The battery life and time to fully charge your device may vary as per usage and other factors.</p> <p>CHARGE COLORFIT MIGHTY</p> <ul style="list-style-type: none"> • Plug the USB cable into a power adaptor. • Plug the power adaptor into an electrical socket. (Power adaptor not included) • Place the magnetic charger on the magnetic charging points of the watch. • While your watch is charging, the screen will show the time, battery percentage and charging progress. • Once the battery is fully charged, remove the charger. <p>User Manual for ColorFit Mighty</p>	<p>POWER ON</p> <ul style="list-style-type: none"> • Press and hold the rotating crown for a few seconds to turn on the watch. <p>POWER OFF</p> <ul style="list-style-type: none"> • Press and hold the rotating crown for a few seconds. • Select 'Power Off' and confirm to power off. <p>WAKING UP THE WATCH</p> <p>To preserve battery, the watch screen turns off when not in use. Turn the screen back on by:</p> <ul style="list-style-type: none"> • Pressing the rotating crown <p>User Manual for ColorFit Mighty</p>	<p>WATCH NAVIGATION</p> <p>The ColorFit Mighty smartwatch has a TFT touchscreen. Navigate the watch by tapping on the screen, swiping side to side, up and down and pressing and rotating the crown.</p> <p>CROWN NAVIGATION</p> <ul style="list-style-type: none"> • Press the crown to turn on the watch display • Press the crown to exit a feature. • Rotate the crown to navigate through the various watch features. <p>HOME SCREEN NAVIGATION</p> <p>The home screen is the watch face. From the home screen:</p> <ul style="list-style-type: none"> • Swipe right to check your Daily Brief. • Swipe left to check your Activity data. • Swipe up to go to quick settings. • Swipe down to check message notifications. <p>User Manual for ColorFit Mighty</p>	<p>SETUP</p> <p>Before pairing, make sure that your smartphone and smartwatch are next to each other.</p> <ul style="list-style-type: none"> • Turn on Bluetooth and the location on your mobile device. • On your smartphone, download the NoiseFit app from the Play Store or the App Store and install it. • The app will ask for personal information such as gender, birthday, height, weight and step length to calculate your stride length, distance covered and calorie burn rate. <p>Note: Ensure that your smartphone is running on Android 9+ or iOS 11+ and is connected to mobile data or a Wi-Fi network.</p> <p>User Manual for ColorFit Mighty</p>	<p>PAIR THE WATCH</p> <ul style="list-style-type: none"> • Open the NoiseFit app and allow the Bluetooth and GPS positioning to be turned on. • Feed in your personal information and health goals in the app. • Go to 'Add Device' page in the app, select the device type and link the watch. <p>Or you can follow the steps below:</p> <ul style="list-style-type: none"> • Turn on the watch. • Scan the QR code from the NoiseFit app on your phone. • Select 'Pair with device' and wait for it to pair. • Select 'Add Device'. Choose your device from the range of devices. <p>On iOS: Choose Bluetooth pairing when you receive a pairing prompt. On Android: Connect it directly.</p> <p>User Manual for ColorFit Mighty</p>	<p>BLUETOOTH CALL CONNECTIVITY</p> <p>To establish Bluetooth calling connectivity, follow these steps.</p> <p>FOR AUTOMATIC CONNECTION</p> <ul style="list-style-type: none"> • After pairing the watch with the NoiseFit app, the watch's calling Bluetooth would be activated. • Now connect it to your phone's Bluetooth to use the calling feature conveniently. <p>MANUAL CONNECTION</p> <p>In case the Bluetooth calling connectivity has not been established earlier, you will have to do the steps manually.</p> <ul style="list-style-type: none"> • Go to Settings. • Search for the device and pair your smartphone to attend calls from the watch. <p>BLUETOOTH CALL CONNECTIVITY REMOVAL</p> <ul style="list-style-type: none"> • In Android devices, to remove the Bluetooth connection, you can unpair from the app and the phone's Bluetooth settings. Go to the phone's Bluetooth settings and forget 'ColorFit Mighty'. • In iOS devices, to remove the Bluetooth connection, you can unpair from the app and the phone's Bluetooth settings. Go to the phone's Bluetooth settings and forget 'ColorFit Mighty' and 'ColorFit Mighty Calling'. <p>User Manual for ColorFit Mighty</p>	<p>WORKOUTS</p> <p>Tap on 'workouts' and select your preferred form of exercise.</p> <p>WORKOUT RECORD</p> <p>The Workout record feature allows you to keep a track of all your workouts done in the past.</p> <p>ACTIVITY</p> <p>Tap on 'Activity' to get a detailed daily activity report on calories burned, steps taken and distance covered. You can set or edit your daily activity goals on the NoiseFit app while setting up the watch.</p> <p>HEART RATE</p> <p>Select the Heart rate feature to start measuring. Ensure that there is no gap between the back panel of the watch and the wrist. Hold still while it measures your heart rate.</p> <p>User Manual for ColorFit Mighty</p>
---	--	---	---	---	--	--	---	--	--	--

<p>SPO2</p> <p>The smartwatch supports viewing the highest and lowest values of SpO2 levels of the day. Ensure that there is no gap between the back panel of the watch and the wrist. Hold still while it measures your blood oxygen level.</p> <p>SLEEP</p> <p>Tap 'Sleep' to view your previous sleep duration. You can view your most recent sleep records and sleep quality in various sleep stages on the NoiseFit app.</p> <p>BREATHE</p> <p>The Breathe feature lets you adjust your breathing rhythm at your convenience.</p> <p>CALL</p> <p>Tap on 'Call' to access the dial pad and view your contacts.</p> <p>FAVORITE CONTACTS</p> <p>Store up to 10 contacts via the NoiseFit app and view them by tapping on Favorite contacts.</p> <p>User Manual for ColorFit Mighty</p>	<p>ALARM</p> <p>Set and remove alarms by tapping on Alarm.</p> <p>WEATHER</p> <p>ColorFit Mighty supports weather viewing in your current location as long as it is synced with the NoiseFit app. You can view today's current weather and for the next 4 days as well.</p> <p>STOPWATCH</p> <p>A stopwatch can be set on the watch. You can also set lap times in the stopwatch.</p> <p>TIMER</p> <p>You can set a countdown with a pre-set duration on the watch or set your own time and it will remind you when the time is up.</p> <p>MUSIC CONTROL</p> <p>You can control your favourite songs and podcasts that play from your phone, right on your wrist as long as the watch is connected with the NoiseFit app on your phone.</p> <p>User Manual for ColorFit Mighty</p>	<p>CAMERA REMOTE</p> <p>You can use this feature to use the camera remotely from the watch.</p> <p>FIND MY PHONE</p> <p>This feature helps you find your mobile device by making it ring. Just tap on 'Find my phone', click on the start button on the bottom and your phone will start to ring, even if it is on Silent mode.</p> <p>FLASHLIGHT</p> <p>You can use this feature to turn on the screen brightness and see your surroundings better. Go to the Flashlight. Tap to use it on.</p> <p>User Manual for ColorFit Mighty</p>	<p>SETTINGS</p> <p>WATCH FACES</p> <p>Click on 'Watch Face' to access your saved watch faces. Swipe left/right to navigate. You can customise your watch face on the NoiseFit app.</p> <p>DISPLAY</p> <p>Tap on Display to adjust your watch's brightness, and timeout duration and turn the Raise to Wake feature on and off.</p> <p>REMINDERS</p> <p>Select 'Reminders' to set your preferred reminder. You can add or edit reminders on the NoiseFit app.</p> <p>DO NOT DISTURB</p> <p>Tap on 'Do not Disturb' to turn off notifications and even schedule when you want your watch to be on do not disturb mode. You also have the option to turn on Smart Mode where, if the watch detects that you are asleep, it will no longer notify or vibrate except for alarms and timers.</p> <p>User Manual for ColorFit Mighty</p>	<p>BATTERY</p> <p>Check your watch's battery levels and turn on Power Saving Mode to conserve battery.</p> <p>GENERAL</p> <p>Tap on General to change the app view, increase or decrease vibration intensity and power off, reboot and reset your watch.</p> <p>ABOUT</p> <p>Tap on About to view the device information.</p> <p>User Manual for ColorFit Mighty</p>	<p>QUICK SETTINGS</p> <p>You can swipe up from the watch's home screen to gain quick settings access.</p> <p>DND MODE</p> <p>POWER SAVING MODE</p> <p>BLUETOOTH CALLING</p> <p>BRIGHTNESS</p> <p>RAISE TO WAKE</p> <p>SETTINGS</p> <p>User Manual for ColorFit Mighty</p>	<p>DEVICE INFORMATION AND TIPS</p> <p>DEVICE INFORMATION</p> <p>The ColorFit Mighty smartwatch contains the following:</p> <ul style="list-style-type: none"> • 1.96" TFT screen display (240*286 px) • Bluetooth calling (built-in microphone & speakers, recent calls, dial pad, contacts) • IP67 water-proof <p>The ColorFit Mighty smartwatch stores your activity data for up to 4 days in between the time you sync your watch to the NoiseFit app. Activity data includes your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the app daily.</p> <p>User Manual for ColorFit Mighty</p>	<p>How do I find my watch's current firmware version?</p> <p>You can find the watch's current firmware on the watch. Go to Settings on the NoiseFit app. Select Device information, choose Check for updates and update if any update is available.</p> <p>How does the watch estimate how many calories have been burned?</p> <p>ColorFit Pulse estimates how many calories you've burned based on the physical activity data and your heart rate.</p> <p>How do I change my activity goals?</p> <p>You can do it through the NoiseFit app. Go to 'My Profile', Go to 'Setup' and select 'My Objectives'. Change your goals and confirm.</p> <p>TIPS</p> <p>How do I update my ColorFit Mighty?</p> <p>You can update your ColorFit Mighty via the NoiseFit app. Go to 'My Profile' and select 'Check for updates'.</p> <p>User Manual for ColorFit Mighty</p>	<p>How do I log my weight?</p> <p>You can log in your weight the first time you set up your NoiseFit app. However, you can update the weight later via the NoiseFit app. Go to My Profile, select Personal Information and change or update your weight. You can update your birthday, height, country and e-mail ID as well.</p> <p>DISPOSAL AND RECYCLING INFORMATION</p> <p>Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return the electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details of this are defined by the national law of the respective country. By recycling, reusing materials or other forms of utilising old devices, you are making an important contribution to protecting our environment.</p> <p>REGULATORY INFORMATION</p> <p>USA: Federal Communications</p> <p>Commission (FCC) Statement</p> <p>This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:</p> <ul style="list-style-type: none"> • This device may cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. • Changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate the equipment. <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.</p> <p>This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. <p>User Manual for ColorFit Mighty</p>	<p>The ColorFit Mighty watch is not a toy. The watch contains small components that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, devices and services are not a medical device and are not intended to diagnose, treat, cure or prevent any disease. We develop products and services to track daily activity and wellness information as accurately as possible. The accuracy of devices is not intended to be equivalent to medical devices or scientific measurement devices. In some cases, prolonged use of products may cause skin irritation. Prolonged contact may contribute to skin irritation or allergies. To reduce the possibility of irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel soreness, tingling, numbness, burning or stiffness in your hands or wrists while or after wearing the watch, please immediately discontinue use.</p> <p>MAINTENANCE INSTRUCTIONS</p> <ul style="list-style-type: none"> • Keep the device dry and clean regularly and especially after prolonged use as moisture and dirt can build up underneath the band and can cause skin irritation. • Do not wear the device too tight but make sure that the bottom sensor is lightly in contact with your skin and there is a gap of about one finger's width between the wrist strap and your wrist. • Do not use household cleaners to clean the device. Use soap-free cleaners instead. • For stains that are difficult to remove, it is recommended to scrub with alcohol. • The device is not suitable for diving, swimming in the sea or saunas; it is suitable for swimming pools, showers (cold water) and swimming in shallows. • Keep it away from direct sunlight, high temperatures or humid conditions as it may damage the band over time. <p>User Manual for ColorFit Mighty</p>	<p>CUSTOMER SUPPORT</p> <p>If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at link: https://support.gonose.com/support/home</p> <p>User Manual for ColorFit Mighty</p>
--	---	--	--	---	--	--	--	--	---	--