

BESA

BS

The serial number is stamped on every valve. You will find it in the place shown

