

## Valvehead




Head A (gastight with easing lever)



Head B (gastight with lifting button)



Head C (gastight with cap)




Head D Head E (with lifting button) (with supported lifting button)




Head F (gastight with handwheel)


## Valvehead



Head G (gastight with handwheel and lifting button)




Head H (pneumatic lifting head)




Head M (manual lifting head)



Head T (sensor)



Head AT (sensor)



Head HT (sensor)