


Winter Bag / Summer Cover




Converting the W	/INTER BAG into
the SUMMER COVER	

1. Remove Part A



The Winter Bag/Summer Cover is designed to custom-fit our outdoor products and effortlessly protect your product with simple adaptation of installation as you transition from Summer to Winter.

The cover includes weatherproof zips and seams in addition to hardy thick waterproof material that is highly resistant to mould, tearing and fading, keeping your product safe from the elements all year round. You do not need to remove the glass fire screen before covering.



Disclaimer. All product specifications and data are subject to change without notice and believed to be correct at the time of publication. MAD Design Group (MDG), its affiliates, agents, and employees, and all persons acting on its or their behalf (collectively, "MAD Design Group"), disclaim any and all liability or any errors, inaccuracies or incompleteness contained herein or in any other disclosure relating to any product. MDG disclaims any and all liability arising out of the use or application of any product described herein or of any information provided herein to the maximum extent permitted by law. The product specifications do not expand or otherwise modify MDGs terms and conditions of purchase, including but not limited to the warranty expressed therein, which apply to these products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document or by any conduct of MDG. Customers using or selling MDG products not expressly indicated for use in such applications do so entirely at their own risk and agree to fully indemnify MDG for any damages arising or resulting from such use or sale. Please contact authorised personnel from MDG to obtain written terms and conditions regarding products designed for such applications. Images are indicative only.