

MAEN

USER GUIDE

**ABOUT THE HUDSON AUTOMATIC
CERTIFIED SWISS MADE**

USING YOUR WATCH

**OVERVIEW
SETTING THE MAEN HUDSON AUTOMATIC**

SERVICE

**CARING FOR YOUR HUDSON AUTOMATIC
WARRANTY**

Wearing the watch for the first time


Before being worn for the first time, or if it has stopped, a MAEN watch must be wound manually in order to function correctly and precisely. To wind the watch manually, unscrew the winding crown completely, then turn it several times clockwise. (Turning in the other direction has no effect.) A minimum of 25 turns is required for adequate partial winding.

The watch will then be wound automatically as long as it is worn on the wrist. Carefully screw the crown back down against the case to ensure waterproofness.

The Hudson Automatic

The Hudson Automatic was born out of our love for vintage watches. There is something special about a vintage watch that is hard to explain. We like watches that effortlessly combine elegance with functionality and that is also what we wanted to achieve with our Hudson Automatic.

The Hudson Automatic is a vintage inspired dive watch with many faces. It can be worn as an elegant watch, but at the same time it can accompany you with confidence on your nautical adventures.





Certified Swiss Made

The Hudson Automatic is our first Swiss Made watch and will be assembled in La Chaux-de-Fonds, Switzerland. Waterproof testing, entrance inspection and final quality control will also be performed in La Chaux-de-Fonds.

The Swiss Made STP1-11 movement will be regulated in 5 positions to Elaboré grade for $-0/+ 15$ sec/day accuracy. Each individual movement will be passing tests to certify the precision of the movement. Next to the regulation, all movements will be equipped with the Incabloc shock protection system. This system protects the balance wheel's delicate pivots from damage in the event of a physical shock.

The Swiss Made label is a representation of the ultimate sign of quality - the perfect combination of function and design.

Hudson Automatic Overview

1

HOUR HAND

2

MINUTE HAND

3

SECONDS HAND

4

DATE WINDOW

5

WINDING CROWN



Setting your Hudson Automatic

SCREWED-DOWN POSITION (POSITION 0):

the crown is completely screwed down against the case. When the crown is in this position, the Hudson Automatic is guaranteed waterproof to a depth of 10ATM = 100 metres (330 feet).

With the closed caseback installed, the water resistance will increase to 20ATM = 200 metres (660 feet)

MANUAL WINDING (POSITION 1):

The crown is unscrewed. To wind the watch manually, turn the crown clockwise; turning in the other direction has no effect.

When setting the watch for the first time or after the watch has stopped, complete a minimum of 25 turns for partial winding.



INITIAL WINDING AND SETTING:

The crown is unscrewed. To wind the Initial winding and setting

- A. Wind the watch manually
- B. Set the time by turning the hands clockwise and by noting the date and day change at midnight
- C. Set the date

To screw the crown back down against the case, return it to position 1 and apply light pressure on it while screwing it down clockwise against the case.

After every use, carefully screw the crown back down against the case to guarantee the waterproofness. The crown should never be unscrewed under water.

Setting the date

SETTING THE DATE (POSITION 2):

the crown is unscrewed and pulled out to the first notch. To set the date, turn the crown clockwise.


SETTING THE TIME (POSITION 3):

the crown is unscrewed and pulled out to the second notch. The seconds hand is stopped, allowing you to set the time to the precise second. To set the hour and minute, turn the crown in either direction. To avoid confusion between a.m. and p.m. hours, move the hour hand to 12 o'clock. If the date changes, it is midnight.

Avoid changing the date after setting the time in a counterclockwise direction between 4 p.m. and 10.30 p.m.



UNSCREW THEN PULL OUT



To screw the crown back down against the case, return it to position 1 and apply light pressure on it while screwing it down clockwise against the case.

After every use, carefully screw the crown back down against the case to guarantee the waterproofness. The crown should never be unscrewed under water.

Caring for you Hudson Automatic

You can help preserve its lustre by cleaning it occasionally with the included microfibre cloth. You can also wash the case and bracelet from time to time using soapy water and a soft brush.

After wearing your watch in the sea, it is important to rinse it with fresh water to remove any salt and sand deposits. Before cleaning your watch, always ensure that the crown is screwed down properly against the case to guarantee waterproofness.

Warranty term: Two year from the date of purchase. This warranty covers manufacturing defects on the watch itself (movement, case, crystal). Other parts than the above are not covered by this warranty. To have replacement covered under this warranty performed, please use our contact form on the "contact us" page. In the e-mail you need to specify your name, address, order number and a detailed description of the issue at hand. Finally, write 'reclaim of purchase' as subject of the e-mail and mail. Note that repair/replacements will be charged in the following cases, even during the warranty term.

- Failure or damage caused by improper use or carelessness (knocks, dents, crushing, broken crystal, etc.)
- Failure or damage caused by unjustifiable repair or modification
- Failure or damage caused by fire or water, or a natural disaster such as for example an earthquake
- Esthetic changes that occur during normal wear and tear and aging (minor scratches, etc.; on the case and/ or crystal, alteration of the colour on the wristband and the peeling of the plating)
- In case the retail store and the purchase date are not indicated on the warranty, or if this information has been rewritten

The case, dial, hands, crystal, watchband or other parts thereof may be replaced with substitutes if the originals are not available. This warranty warrants that you can receive free replacement in accordance with the terms set forth herein and within the specified term, and shall not restrict any lawful right of the Customer.

Any damage caused due to the modification of the watch is not covered by our warranty. Only if the modification is arranged and executed directly via our service center the original warranty will be maintained.

WWW.MAENWATCHES.COM