## **DYNEX-A** MANUAL

Lamplitude

1. Before installing, make sure the power supply is switched off.

2. Follow the steps as the figure for installation or replacement of bulb step.

A. Fix the fixture by insert the spike into the ground.

B. Connect the wires and twist the joint by the mackintosh.

3. After finishing every step, tighten the screws, have the fixture fixed, and then connect the power supply.

Rated voltage: In accordance with the product labeled Rated power: In accordance with the product labeled



## CAUTION

⚠

In case of any doubt, please contact the qualified electrician.

