

ST-ZSQ01 MANUAL

Lampitude



1. The lamp must be installed in rated voltage and assure safety earth.
2. Installing and fixing the lamp should be processed by professional under the condition power off.
3. When change the lamp bulb please noted that the max wattage shouldn't exceed the labeled wattage.
4. If the external electrical wire damage please change by the professional in time in case of any danger.

Rated voltage: In accordance with the product labeled
Rated power: In accordance with the product labeled



CAUTION

In case of any doubt, please contact the qualified electrician.

<p>1 Cut opening in ceiling, according to cut-out size of model number in this manual. Customized products please refer to specification notes. Fix suspension set to the ceiling, make sure of locking the anti-drop hanging cooper parts well.</p> <p>Cut-out: ST-ZSQ01-300: Ø310mm ST-ZSQ01-600: Ø610mm ST-ZSQ01-900: Ø910mm</p>	<p>2 1.The middle plate should be rotated out. 2.Unlock the mesh plates 4pcs in image, the rest 2pcs remained to hold and adjust the frame.</p>	
<p>3 Incline the frame at 45° in the direction of 2pcs mesh plates, put it through the ceiling.</p>	<p>4 Adjust the frame height and keep it horizontal with ceiling; after frame balance and adjustment lock 4 mesh plates again. The frame visible depth 2mm is reserved depth for plastering.</p> <p>Correct installation method.</p>	<p>5 Fix installation frame tightly by self-tapping screws supplied.</p>
<p>6 After putting the mounting parts into the opening hole, fix the lifting gear group with the embedded parts according to 2 items. Put spot modules (per group) into nearby hole positions of the luminaire.</p> <p>Connect power supply cables with driver, making sure of having disconnected the electric power.</p>	<p>8 Turn on switch to test.</p> <p>OFF ON</p>	<p>7 Plastering: Paste wall sticker, flatten, paint and spread an even coat of paint.</p>