

SERIAL #

CERTIFIED BY



* **WARNING:** The Breakers is boosted internally to 18v via a charge pump.

Please do not use greater than a 9v power supply as doing so can and will damage your pedal.

HOW THE KNOBS WORK

LEVEL

Sets the volume of the pedal.

GAIN

All the way left is completely clean.
Turning clockwise increases gain & blends in overdrive.

BASS & TREBLE

Turn right to boost, & turn left to cut.

TOGGLE SWITCH

Up is more compressed with less headroom.
Down is open and clear with more transparency.

SUGGESTED SETTINGS

Preamp



Rhythm



Lead



TS at 12:00

