

Strat® Wiring Diagram

McNelly Standard 5-way Switch

- Position 1 - bridge
- Position 2 - middle and bridge parallel
- Position 3 - middle
- Position 4 - neck and middle parallel
- Position 5 - neck

- Master Volume
- Tone 1 - neck and middle
- Tone 2 - bridge

