

Tele[®] wiring diagram Standard 3-way Switch

Position 1 - bridge
Position 2 - neck and bridge parallel
Position 3 - neck

