

Tele[®] wiring diagram 3-way Switch

Position 1 - bridge

Position 2 - neck and bridge series

(neck pickup cover requires a separate ground wire)

Position 3 - neck

