

# Tele<sup>®</sup> wiring diagram 4-way Switch

- Position 1 - bridge
- Position 2 - neck and bridge parallel
- Position 3 - neck
- Position 4 - neck and bridge series

Note: The neck pickup cover must be grounded separately

