

Outside

"PRODUCTS DESIGNED TO BE MORE PERSONALLY SUITED AND UNIQUE."




What you have purchased is a sophisticated product, meeting the highest quality and safety standards. Please follow the following safety measures strictly:

1. Do not puncture, pierce, or burn this product.
2. Keep out of reach of children.
3. Do not place the product into water or other liquids and keep out of moist environments or else it will cause a short circuit.
4. Do not use other charging cables with this product, other than the charging cable provided in this box. This could cause explosion or product failure.
5. This product should be away from open flames and heat with more than 122 degrees F (50 degrees C). Avoid prolonged sun exposure, especially in a glass case or in a car. Otherwise, it will cause overheating, fire, or functional decline, and reduce the service life.
6. Please disconnect the power immediately after full charge or it will drain the battery life.

DANGER - Extremely flammable. Contents Under Pressure.

Ignite lighter away from face and clothing. Be sure flame is completely out after each use. Contains flammable gas under pressure. Never puncture or put in fire. Do not keep lit for more than 30 seconds. Never expose to heat above 120 degrees F (49 degrees C) or to prolonged sunlight. Refill using butane gas canisters only.
USE ONLY BUTANE GAS.
 Read instructions of the butane refill container. Refill in a well-ventilated area. Refill away from heat source, sparks, or flame. Keep lighter and butane gas out of reach and away from children.

Made in China.
 John Gibson Enterprises, Inc.
 Loves Park, IL 61111
 www.GibsonEnt.com
 www.GibsonWholesale.com



BIOMETRIC MULTIPURPOSE LIGHTER USER MANUAL

Inside

BIOMETRIC FINGERPRINT LIGHTER

Thank you for choosing the Biometric Multipurpose Lighter. This lighter is the only childproof multipurpose lighter in the world, secured by your unique fingerprint. The Biometric Multipurpose Lighter has an electric ignition, magnetic closure, adjustable flame, and a refueling port for butane gas. It is rechargeable with a micro USB cable, included in this gift box. This lighter has a soft touch, matte finish to resist marks, scratches, and fingerprints; and state-of-the-art biometrics. The Biometric Multipurpose Lighter is Another Gibson Original®. Easily program your fingerprint. Once programmed, only your print will ignite the lighter.

- Included:
- 1 Biometric Multipurpose Lighter
 - 1 USB-MicroUSB Charging Cable
 - 1 User Guide


- Upon receiving your lighter
1. Fully charge your lighter before use, about 15 minutes.
 2. Turn the Flame Adjust down to the lowest setting.

FINGERPRINT PROGRAMMING & RESET

To program your fingerprint, open the bottom cap and press the button for 5 seconds until the pale green light flashes slowly. Release the button. Gently touch your thumb flat on the fingerprint sensor three times. With each entry, the pale green light turns deep green and back to pale green. After 3 entries, the pale green light goes out. If the input process is not completed in 1 minute, the pale green light will automatically turn off.

To reset the lighter, open the bottom cap to access the button. Press for 10 seconds. The red light will flash rapidly six times and then turn off. This will clear all fingerprint records. You will need to reprogram the sensor with a new fingerprint to use the Biometric Fingerprint Lighter.

Total number of fingerprints that can be recorded: 120.




RECHARGING - REFUELING

To recharge your Biometric Multipurpose Lighter, connect the USB Cable to the USB port at the bottom of the lighter to charge. The lighter will automatically flash with a red light when the battery is low. Once the battery is full, the light will turn green. The charging time from 0-100% is 15 minutes.

To refuel your lighter, use any universal butane gas refill canister and follow the directions on the canister, or go to www.gibsonent.com for refill instructions.

Battery ignition times per charge: 550-600.
 Gas ignition times per charge: 500.



IGNITION

When you want to use your lighter, pull the red gas release to activate the lighter. The red light will flash slowly. Press your thumb quickly onto the sensor. You will hear the igniter clicking and the lighter will light. The red light will turn deep green, then back to red once the ignition is successful. If the ignition fails, continue to gently and quickly press your fingerprint on the sensor while pulling the gas release. When you are finished using the lighter, release the red gas release switch and the red light will turn off. Do not continue pulling on the gas release switch, as butane gas is released even when the lighter is not fully ignited.

