



Congratulations with your  
2Can Audio Jerrycan speaker



Read this manual before first use of  
the speaker.

## How it works

1. Blue LED - bluetooth indicator  
The blue LED flashes. The speaker is ready to connect with bluetooth.  
The blue LED lights constantly, the speaker is connected with a device via bluetooth.
2. Antenna  
The antenna takes care of a solid bluetooth range of about 15 meters.\*
3. On/ off switch  
The white LED ring lights up when you power on the speaker.
4. Red LED - charge indicator  
When the speaker is charging the red LED lights constantly. If the speakers battery is completely full, the red LED turn off.
5. Charge connector  
Connector (2.5 5.5) for charge with the supplied cables.\*\*
6. Volume knob  
You can change the volume on the speaker.

\* Obstacles can affect range

\*\* Only use cables obtained through 2Can Audio



## Quick start

### Power on;

Make sure the battery is charged.

Press the on / off switch (3). The white LED lights up. The speaker is now on.

### Connect;

The blue LED (1) flashes, the speaker is ready to be connected to a bluetooth device. Turn on bluetooth on your device and search for "2Can Audio". Click on 2Can Audio to establish the connection. The blue LED now lights constantly, the connection was successful.

### Enjoy;

You choose what to play through your device. You can also adjust the volume with your device. The volume can still be adjusted separately with the volume knob (6).

### Charge;

When the speaker is empty due to the fine beats, charge the speaker with the supplied cable via the charging port (5). The red LED lights up constantly. When the red LED goes off, the speaker is fully charged.

## Specifications

- 2 x 50 watt amplifier
- 8 hours playtime (volume and media can increase the playtime)
- 2 hours chargingtime (only use the supplied charger \*can be optionally reordered)
- 15 meters bluetooth range (obstacles can affect the signal)
- LED indicators

## Guarantee

Obviously, the warranty lapses because, among other things:

- the speaker has been used differently than intended.
- the speaker has been opened by someone not authorized by 2Can Audio.
- the speaker has been exposed to open flames / fire.
- the speaker has overheated due to being in direct sunlight (too long).
- the speaker shows water damage, the speaker is not waterproof.
- a charger was used that was not purchased through 2Can Audio (or official dealers).
- the speaker has (serious) fall damage.
- the speaker has been used incorrectly, other than as described above.

For questions regarding the warranty, please contact us at [info@2canaudio.com](mailto:info@2canaudio.com)