## High Torque Bearing Kit Addendum

## High Torque Bearing Kit Seal Installation

Please install the seal with the flat side facing the transmission (showing). If you have any further questions, please give us a call at 517-339-3835.



