



SPECIAL INSTRUCTIONS

Provided in your builder's kit is an inner primary bearing race manufactured to meet the specifications of BAKER Drivetrain products. It will be necessary to replace your old H-D bearing race with the one provided when swapping the transmission from your bike.

When installing the primary race be sure to use a small amount of green Loctite to prevent the race from "walking" on the mainshaft under load.