


# Craighill

## CUFF SIZING


Measure the circumference of your wrist using our tape measure. You can also use string and then lay it out flat on a ruler to measure the distance. If your wrist measurement falls in between a size, determine if you prefer a loose or snug fit and size up or down accordingly.

*Please note that all Swing Cuffs are finished by hand and slight variations in cuffs can occur. All cuffs shown at full scale.*


### SWING CUFF



**Small**  
5.25 – 6"



**Medium**  
6.25 – 7"



**Large**  
7" – 7.75"

