




PURSUIT

RELEASE ADJUSTMENT INSTRUCTIONS



TRAVEL ADJUSTMENTS


To adjust the trigger travel of your Pursuit release, locate the cap head screw at the base of the hammer [Fig. 1]. To increase travel, turn the screw counter clockwise. To decrease travel, turn the screw clockwise. To achieve the recommended setting, cock the release by pressing in the hammer and turn the screw clockwise until the release fires. Then turn the screw counter clockwise 1/8 to 1/4 turn. This is the optimal setting for your Pursuit release.



[Fig. 1]

LENGTH ADJUSTMENTS

To adjust the length of your Scott™ Release with a Rope Strap Connector (RSC), loosen the two #4-40 socket head cap screws that attach the lock-down clamp [Fig. 2] to the triangular metal bracket sewn to the release strap. Slide the RSC to the desired webbing length and retighten both screws.



[Fig. 2]

FINGER EXTENSION

Use a 3/32" Allen key [Fig. 3] to interchange the supplied 3 and 4-finger extension.



[Fig. 3]

WARRANTY SERVICES:

IMPORTANT: In the unlikely event that you require service on your product, please contact Customer Service at 1 (877) 503-5483. If necessary, our Customer Service Agents will provide you with a Return Merchandise Authorization [RMA] number and instructions on how to ship the product(s) back. **It's important that you contact a Customer Service Agent before returning any item.** Please be sure to include your RMA number when returning an item, so that we can identify the return as yours. Without the RMA, we will not be able to process your return, and your item will not be returned to you.

PATENT INFORMATION:

This product maybe covered by one or more patents. A complete list of Scott Archery patents can be found by visiting scottarchery.com/pages/patents

THANK YOU FOR CHOOSING SCOTT!

The Outdoor Group, LLC
1325 John Street - West Henrietta, NY 14586
1 (877) 503-5483
www.scottarchery.com



LIABILITY DISCLAIMER

The Outdoor Group, LLC is not liable for any personal injury, death, or property damage that may result from your use of this product. The user of this product assumes all risks of property damage or injury to yourself and others that may arise from its use. Use of this product binds the user to this agreement.