



# Bat Signal Installation

**DANGER ELECTRICAL SHOCK**





Pinball machines have high voltages which can cause **DANGER TO LIFE AND LIMB**. **TURN POWER OFF** and **UNPLUG PINBALL MACHINE** prior to installation. Pinball machines are high voltage and can cause electrical shock.

1. Remove the glass and pull the playfield into resting position. Remove the plastic piece held by the
2. Insert the wiring harness through the hole in the playfield.



3. Re-attach the plastic piece and place the Bat Signal on the upper right corner as shown below

4. Lift the playfield all the way up (make sure to remove/secure the balls), place the wiring harness as shown, connect the alligator clips from the wiring harness to the bulb socket shown below.



**5. Check for clearances prior to the game play.**