

LORD OF THE RINGS INTERACTIVE SWORD INSTALLATION



DANGER ELECTRICAL SHOCK



Pinball machines have high voltages which can cause DANGER TO LIFE AND LIMB. TURN POWER OFF and UNPLUG PINBALL MACHINE prior to installation. Pinball machines are high voltage and can cause electrical shock.

1. Remove glass and pull the playfield into resting position
2. Carefully feed the wiring harness through the hole underneath the sword plastic #03




3. Place the sword mod by attaching it's brackets onto the existing screws on plastic #04



4. Make sure the sword is tightly secured, remove pinballs, and lift the playfield all the way up

5. Locate the flasher wires and replace its Z-connector in between with the new sword's one



6. Make sure to check for clearances prior to starting the game play.