

# The Loud Mouth Infrared Curling Iron

## PRODUCT PROFILE:

- 70-82 watts
- Dual voltage 100-240V/110V 50/60Hz
- LCD display
- Temperature 80-210C/180-410F
- 60 minute auto safety shut off
- Two sizes available 25mm/32mm
- Long 360° swivel power cord and ergonomic design for ease of use
- Cool touch tip for more control
- Infrared heat seals in hair's natural moisture and produces a healthier, longer lasting shine
- Intelligent constant temperature
- Fast 60 second heat up
- Ceramic barrel with black diamond and black graphene coating minimizes hair damage, has fast heat transfer, high thermal conductivity, and a scratch resistant surface.



## OPERATION:

1. Insert the plug of the curling iron into an electrical outlet, ensuring that the plug matches the socket.
2. Turn on your curling iron by pressing the ON/OFF button.
3. Select your desired temperature by pressing the + or - buttons.
4. Once your appliance stops counting up or down to the desired temperature, wait one minute for it to heat up and it will be ready to use.
5. When you are finished, press the power button to shut off your appliance and then remove the plug from the electrical outlet.
6. Never use this appliance near water.
7. The product will remain hot after each use. Place on a heat resistant stand or surface and avoid any contact.
8. Safety precautions included, but not limited to those stated herein, should be observed at all times while appliance is in use, especially if the appliance is used around children.
9. To avoid heat damage, refer to the recommended heat settings below. If you are unsure which temperature to set your appliance at, start at a low heat setting and gradually increase the temperature until you are able to achieve your desired results.

## RECOMMENDED HEAT SETTINGS:

- Delicate, thin, easy to curl hair  
180F - 285F
- Average to thick or color treated hair  
285F - 320F
- Thick, wavy, or coarse hair  
320F - 410F

## INSTRUCTIONS FOR USE:

1. Use on dry hair only.
2. Brush hair prior to using the curling iron and curl section by section.
3. Allow your hair to cool before running your fingers through it.
4. For longer lasting curls, pin each curl up as it cools before allowing it to fall.
5. Use the cool tip while curling to avoid burns or scalding.

## WARNING:

The barrel will be **HOT!**  
To avoid scalding, **DO NOT TOUCH** the barrel while the curling iron is heating up, during operation, or after use until it has completely cooled down.



32mm/25mm  
Loud Mouth Curls

### CARE:

- After powering off, unplug the curling iron and let it cool down.
- Do not rinse with water as it may damage the appliance. For cleaning the handle or barrel, wipe with a moist cloth. Do not use harsh products, benzene, or paint thinner as it may damage your appliance.
- Clean after each use to avoid build up; especially when using with hair products.

### STORING:

- Turn the appliance off by pressing the power button. Unplug from the outlet.
- Be sure that the barrel has cooled down completely before handling. Do not wrap the cord around the appliance.
- Store in a dry, safe place out of the reach of children.

### WARNING: KEEP OUT OF THE REACH OF CHILDREN!

As with most electrical appliances, parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:

- Always unplug after use
- DO NOT use while bathing, in the shower, near basins or other vessels containing water.
- DO NOT store or place this appliance where it can fall or be pulled into a bathtub or sink.
- DO NOT submerge or drop into water or other liquid.
- Do not use if there is damage to the electrical cord.

### WARNING!

To reduce risk of electric shock, burns, or injury to self or persons:

- An appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is being used on, or near children or individuals with certain disabilities.
- If the appliance is not working properly, has been dropped, damaged, or submerged in water, contact *Head Kandy* for repair or replacement options.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use while sleeping.
- Do not use with an extension cord.
- Do not use this appliance with a voltage converter.
- Product is hot when in use. Do not let eyes or bare skin touch heated surfaces.
- Use this appliance only for its intended use as described in this manual.
- Do not wrap cord around the appliance.
- Do not use if the power cord is damaged. In the event of damage, discontinue use immediately and contact *Head Kandy* for repair or replacement options.
- Do not use any harsh or abrasive cleaners on the product.

### FOR HOUSEHOLD USE ONLY

This appliance may have a polarized plug. As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

### LIMITED 1-YEAR WARRANTY

This warranty is for the original purchaser of the *Head Kandy* Loud Mouth and is nontransferable. Head Kandy LLC warrants that this appliance will have no defects in material and workmanship under normal household usage for 1 year from the date of purchase.

Keep the original sales receipt for proof of purchase to attain warranty provisions. For 1 year from the date of purchase, Head Kandy LLC will repair or replace, on its own accord, any *Head Kandy* Loud Mouth or parts found to be defective. This warranty does not cover any shipping or handling charges which may incur. This warranty does not include any damages caused by misuse, accident, neglect, abuse, use with a voltage other than what's marked on the product, or for commercial purposes.

If your *Head Kandy* Loud Mouth is found to be defective within the time period of this warranty, please contact the Head Kandy LLC warranty department. If the product is discontinued or no longer available, a replacement may be made with a similar product of equal or greater value. Any attempt to repair or service this product on your own will void the warranty.

*Head Kandy*

1-800-937-1917

warranty@headkandypro.com

office@headkandypro.com

131 Crane Lane  
Salida, CO 81201