

GO GETTER

Lemon Scented Hard Wax Gentle Enough for Sensitive Skin

WHAT'S INCLUDED:

16.9 fl oz Capacity Wax Warmer US Plug 110V, 100W Temperature Range: 95-257°F Aluminum Wax Pot 20 Large Applicator Sticks 20 Small Applicator Sticks 3.4 FL OZ 100ml Before Wax Spray 3.4 FL OZ 100ml After Wax Spray (3) 3.5oz Hard Wax Bead Bags (No strips needed!)

When plugging in the wax warmer the screen display will read OFF. To turn the wax warmer on adjust the control knob clockwise. The rotary switch can be adjusted to set the temperature by 34°F with each turn. To lower the temperature turn the control knob counterclockwise. When the temperature is adjusted to the lowest setting, turn the control knob counterclockwise to power off. The indicator light will be red when preheating and change to green when the warmer has reached the desired temperature.

SAFETY WARNINGS:

ALWAYS USE CAUTION. HOT WAX CAN BURN YOU.

As with any other electrical appliance, keep out of reach of children. Read through the instructions prior to use. DO NOT place, store, or use the device near water or where it can be pulled into water. DO NOT submerge in water; keep surrounding area dry. If the warmer falls into water unplug it immediately. DO NOT reach into the water. Even when the warmer is off electrical parts are still live and can cause injury.

All metal compontents can reach up to 257°F and will be hot to the touch.

PRECAUTIONS:

Test a small area to make sure your skin is not overly sensitive to the wax. Avoid waxing over cuts or scrapes. If you are on medication that affects the skin or have a skin related disorder, consult your doctor prior to use. To avoid irritation do not repeatedly wax over the same area.

HOW TO CLEAN THE SILICONE WAX POT:

If the wax does not easily pop out, use an applicator stick to remove leftover wax. Pour baby or body oil into the silicone wax pot and heat until the remaining wax dissolves. Once cooled wash with soap and water to thoroughly remove all oil residue. Pat dry with a paper towel.

INSTRUCTIONS FOR USE:

Add hard wax beads to the digital wax warmer silicone pot and allow to melt until the wax becomes the consistency of thick honey. Before you begin use an applicator stick to test the wax temperature on the inside of your wrist. **Use with caution, hot wax can burn you.** Wax should spread easily without being uncomfortably hot. If the wax is not warm enough for proper adhesion it will need to be heated and applied at a higher temperature. Always test prior to use when making temperature adjustments.

Cleanse the area to be waxed with our Before-Wax Spray. Apply using a cotton ball and pat dry. Dip your applicator stick into the melted wax and twirl to avoid dripping. Apply wax in the direction of hair growth. When the wax has dried and fully hardened press down on the patch of wax to ensure uniform removal. While holding the skin taut quickly pull the wax in the opposite direction of hair growth. Once you have finished apply After-Wax Spray to soothe skin and remove any residue. Discontinue use if reaction occurs.

TROUBLESHOOTING:

If the wax is not pulling up all of the hair you may not be applying enough pressure with the applicator stick. Apply with more pressure so that the hairs are coated in wax. The wax may not adhere to hair that is too short. One quarter inch is the ideal length for hard wax hair removal.

If the wax is not sticking to your skin, you may have too much Before or After-Wax spray on the area. Blot dry or massage into skin so that it's only slightly shiny. If the wax is cracking or coming apart when you try to peel it off it may have been left on too long or applied too thin.

Distributed by Head Kandy, LLC Salida, CO 81201 800-937-1917







headkandypro.com