


























Example: 1 profile per device








							
Profile name	Profile color	Action / device	Rotate Normal position	Rotate sideways	Rotate upside down	Swipe up & down, right & left	Navigation / On-Off
Samsung TV		Action:	Change channel	Adjust volume		On / Off, Source	Smart menu navigation
		Device:	Samsung TV	Samsung TV		Samsung TV	Samsung TV
Settop box		Action:	Change channel	Adjust volume		On / Off, Source TV - Radio	TV Guide navigation
		Device:	Settop box	Settop box		Settop box	Settop box
Sonos		Action:	Track change	Adjust volum	Adjust volume	Play / Pause	Volume, track, play / pause
		Device:	Sonos Living room	Sonos Living room	Sonos Kitchen	Sonos Living room	Sonos Living room
Philips Hue		Action:	Brightness	Brightness	Brightness		
		Device:	Hue light 1 & 2	Hue light 1	Hue light 2		
Apple TV		Action:				Source TV	Menu navigation
		Device:				Apple TV	Apple TV
		Action:					
		Device:					
		Action:					
		Device:					

Example: 1 profile per action

							
Profile name	Profile color	Action / device	Rotate Normal position	Rotate sideways	Rotate upside down	Swipe up & down, right & left	Navigation / On-Off
<i>On / Off</i>		Action:	Brightness	Brightness	Brightness	Source	On / off
		Device:	Hue 1 + 2 + 3	Hue 4 + 5	Hue 1 - 5	Samsung TV	Samsung TV, settop box
<i>Watch TV</i>		Action:	Change channel	Adjust volume	Brightness	Source	TV Guide navigation
		Device:	Humax settop box	Sonos Playbar + Sub	Hue 1 & 3	Samsung TV, Humax settop box	Humax settop box
<i>Watch movie</i>		Action:		Adjust volume		Play / Pause	Menu navigation
		Device:		Sonos Playbar + Sub		Apple TV	Apple TV
		Action:					
		Device:					
		Action:					
		Device:					
		Action:					
		Device:					
		Action:					
		Device:					

Use of profiles: you can decide



Profile name	Profile color	Action / device	Rotate Normal position	Rotate sideways	Rotate upside down	Swipe up & down, right & left	Navigation / On-Off
		Action:					
		Device:					
		Action:					
		Device:					
		Action:					
		Device:					
		Action:					
		Device:					
		Action:					
		Device:					
		Action:					
		Device:					
		Action:					
		Device:					