



24-HOUR DIAL (For some models)

Position of eyes may vary with model.

This diagram will simplify following the step-by-step setting instructions. Match it to the face of your new Caravelle watch. Note that the DAY dial is at 9 o'clock, the DATE dial is at 3 o'clock, and the 24-HOUR dial is at 6 o'clock. The watch CROWN has three specific positions. You will hear a "click" when the crown is pulled out (or pushed back) from one position to another. Once the watch is set properly, except for date variations or time zone changes, adjustment is rarely, if ever, required.

SETTING THE TIME

1. When the second hand reaches 12 o'clock (the zero or 60th second mark), pull the crown all the way to the "OUT" position (you will hear two "clicks"). All hands will stop.
 2. Turn the crown to move hands FORWARD (clockwise) until the day indicator jumps to the center of the day desired (SUN, MON, etc.). This establishes midnight, the beginning of the day.
 3. For AM time, continue to move hands forward until the minute hand is approximately 5 minutes beyond the desired minute marker; then, gently turn back to the same marker. For PM time, follow the same procedure, but first advance the hands past 12 o'clock.
- Note:** The date will advance automatically at midnight, provided that AM and PM have been established (Steps 2 and 3). The watch calendar is programmed for a 31-day cycle. Therefore, on the first day of any month following a month with fewer than 31 days, the date must be advanced manually (see Step 5).
4. When the time standard by which you are setting your watch (e.g., telephone beep) reaches the 60th second, push the crown all the way to the "IN" position. All hands will start instantly.

SETTING THE DATE

5. To set the date, pull the crown to the "INTERMEDIATE" position (one "click"). Turn crown slowly to advance the date indicator to the desired date.

Note: The date should never be changed manually between 9:00 pm and 3:00 am as this might affect the calendar mechanism and the accuracy of the date. (The mechanism will not be damaged if the crown is turned accidentally during this time period, however.)

6. Push the crown to the "IN" position. Your watch is now operating normally.

24-HOUR TIMING (FOR SOME MODELS)

The 24-hour dial will be synchronized with the regular time, provided that midnight has been established (Steps 2 and 3).

ABOUT THE POWER CELL

Your new Quartz Watch has a fresh power cell designed to provide maximum reliability for approximately a year under normal use. If the cell is not replaced before it is exhausted, the watch will simply stop. The mechanism should not be harmed in any manner. However, when the power cell becomes exhausted, it should be removed at your earliest convenience to diminish the possibility of leakage. Never store your watch with an exhausted power cell in it. The watch should be brought to an authorized Bulova dealer for replacement of the power cell. For best performance, the proper power cell should be used.

Note: When the crown is in the "OUT" position, the motor and hands stop. Only the quartz crystal continues to vibrate, using very little power. If the watch is to be stored for a length of time, it is recommended that the crown be left in the "OUT" position to prolong battery life.

This does not apply to models with two hands only.

WATER RESISTANCE

Watch models marked only "Water Resistant" on the case back, without additional depth markings are not to be used for swimming. For swimming, models that have the additional marking of "50m," "100m" or "200m" are recommended.