



ACCORDING TO THE OWNERS MANUAL, THE COLUMN SHOULD BE PLACED A MINIMUM 1" (INCH) AWAY FROM THE BOAT (TYPICALLY THE RUB RAIL)