



Party, Tents & Events
707-544-4132
pterentals.com

Frozen Drink Machine

IMPORTANT

Be sure equipment is connected to properly grounded 120 volt power supply with 15 amp circuit. Make sure all plastic is snapped into place. Plug machine directly into an outlet. If you **must** use an extension cord, use only a No. 10 wire cord as short as possible. **DO NOT** use machine in direct sunlight.

USE FROZEN DRINK MIX ONLY
USE OF ANY OTHER PRODUCT MAY RESULT IN IMPROPER
FREEZING



Mixing

Mocktail - Non-Alcoholic

Mix one bottle (½ gal. of concentrate) with 2 gallons of water (hint: use empty mix bottle 4x)

Cocktail - With Alcohol

Mix one bottle (½ gal. of concentrate) with 1 ½ gallon of water (hint: use empty mix bottle 3x) with ½ gallon of alcohol (Known as a "Handle")

Pre mixing will expedite freezing. Pre-cool the mixture prior to pouring into the machine. Makes approximately 50 - 8 oz. servings. It will take approximately 2 hours for fluids to freeze.

*****Adding alcohol will drastically slow the freezing process*****

We suggest you add alcohol after you have poured the drinks or allow additional mix time. Pour the mixture in to machine's bowl, up to the maximum fill-line. **DO NOT OVERFILL!**

Operation

1. Install the cover and check that it is correctly placed over the bowl.
2. Make sure barrel (container) is correctly snapped in.
3. Set the power switch to "1" **ON** position. **DO NOT** run machine dry (without mix).
4. Set the mixer/refrigeration switch to "11" **FROZEN** position. If mixture begins to over freeze, turn switch to "1" **CHILLED** position.
5. Set the light switch to "1" **ON** position.
6. Refill bowl when running low with pre-mixed, pre-cooled product.
7. **DO NOT LET AUGER SHOW MORE THAN 1/2 WAY BEFORE REFILLING**

Cleaning

1. Empty any remaining contents.
2. Rinse bowl by adding clean warm water, and completely drain.
3. Please **DO NOT** disassemble the machine, we will take care of the rest of the cleaning.