



WHEN LOOKING AT THE FRONT OF THE POPCORN MACHINE, THERE ARE THREE (3) SWITCHES AS FOLLOWS:



6 EASY STEPS TO POP THE BEST POPCORN:

- 1) Turn all switches to "ON"
- 2) ***For the 1st batch only,***
Let the kettle heat about 4 minutes.
- 3) Add the oil bar, then the popcorn seeds.
- 4) Dump the kettle when popping is about 95% completed.
- 5) Repeat steps 3 & 4 and always pop at least 5 batches of popcorn every time you pop.
- 6) ***For final batch only,***
Turn the Kettle Heat Switch "OFF" as soon as corn starts popping rapidly (to raise kettle lid)

WARNING! Keep kettle switches "OFF" when not popping.

CARE & CLEANING INSTRUCTIONS:

➤ Unplug this unit before cleaning.

➤ **DO NOT** clean this machine with Windex or other ammonia cleaners:
It will damage the finish and doors.

➤ Remove any extra kernels or loose popcorn from machine. Use a non-abrasive sponge or cloth with mild, warm/hot soapy water to wipe out machine.

If using your own oil and popcorn the best oil to use is coconut oil you may also use canola, sunflower, peanut or soy. USE 1/3 CUP OIL TO 1 CUP POPCORN FOR EACH BATCH

➤ **Do NOT USE VEGETABLE OIL !!!!!!!!!!!!!!!**