



WRISTBAND AUDIO RECORDER QUICK START GUIDE

SpyCentre.com Spy Shop - Since 1993

Toll Free # 1-800-292-7748

1812- Wristband Audio Recorder

How to Charge the Battery:

1. Connect the audio recorder to a PC or USB power supply with the provided AUX to USB cable
2. Takes 2 hours to fully charge
3. A BLUE flashing light = Charging
4. NO LIGHT = Fully Charged

NOTE: A solid RED light will be present when device is connected to a PC

How to Record a Continuous audio file:

1. Make sure the headphones/data cable is unplugged
2. Slide the Switch to the **ON** position
3. A **RED LED** light will turn **ON** and begin to blink several times, indicating a recording has begun
4. When finished recording slide the Switch to the **OFF** position to end the recording
5. Wait 10 seconds before making another recording

NOTE: If the device runs out of power during the recording, it will finalize and save the file before the battery dies

How to Record a Voice Activated audio file:

1. Make sure the headphones/data cable is unplugged
2. Slide the Switch to the **ON** position
3. A **RED LED** light will turn **ON**
4. Hold down the minus key (-) on top of the recorder next to the on/off switch until the red LED turns **OFF**
5. Once the **LED light** has turned off you will be on and recording with **voice activation**.
6. When finished recording slide the Switch to the **OFF** position to end the recording
7. Wait 10 seconds before making another recording

NOTE: If the device runs out of power during the recording, it will finalize and save the file before the battery dies

How to Playback files on the Device:

1. Use the USB adapter that came with the recorder and plug that in which will convert the USB port into a 3.5mm aux port.
2. From there you will be able to plug your headphones into the recorder.
3. Slide the Switch to the **ON** position
4. A solid LED light will be **ON**
5. hit the (-) **minus** button to switch over to the audio recorded files you created
6. Tapping the (-)**minus** button again it will take you back to the music files.
7. To Play the next file press the (+) button
8. To change the **VOLUME** of the recording being played press and HOLD the (+) or (-) button
9. Turn the switch to **OFF** when done

How to Playback files on a PC:

1. Connect the device to the USB port of the computer
2. When connected the PC will recognize the device as a removable disk
3. Open the **RECORD** folder
4. Open the **VOICE** folder
5. Click the file you wish to play

How to Playback files on a MAC:

1. Connect the device to the USB port of the computer
2. When connected the MAC will recognize the device as a **removable disk**
3. Open the **RECORD** folder
4. Open the **VOICE** folder
5. Click the file you wish to play

How to Playback files on a Google Chrome Book:

1. Connect the device to the USB port of the computer
2. A pop up menu may occur, if so select **“View Files”**
3. If a pop up does not occur, select the **O** icon (called the app launcher) “similar to a windows icon button” located in the bottom left corner of the screen
4. Underneath the Google Drive are My Drive, Downloads, New Services, and something else that may be named **“REMOVABLE DRIVE”**
5. Select the Removable Drive. If unsure of this step. Disconnect the device from the Chrome Book and see what is no longer available under the Google Drive from Step 4
6. After selecting the Removable drive you can now navigate the folders in the main folder to find the recorded files.
7. Double Click to play

NOTE: In order to play back the files on these devices you will need to download an APP that can

play .WAV format. We recommend VLC media player  , available for free at the **APP STORE**

How to Playback files on an Android Smartphone or Tablet:

1. Gather your smartphone, it's charge cable, and the Wristband Audio Recorder with the included **OTG Cable**.
2. Connect the **OTG Cable** to the USB Charge Bank using the Micro USB port
3. Connect the Female USB portion of the OTG cable to your smartphone's USB Charge Cable, and then plug the Micro USB end of your charge cable into your phone
4. Go to your **Device Storage** and look for the **External Memory**. Inside will be all your audio files that you can click on in order to review what was captured.

NOTE: In order to play back the files on these devices you will need to download an APP that can

play .WAV format. We recommend VLC media player  , available for free at the **GOOGLE PLAY STORE**

How to **Delete files** on the **Device**:

1. To **DELETE** files from the device, first put the device in **playback mode**
2. A solid **RED LED** light will be **ON**
3. hit the **(-)minus** button to switch over to the audio recorded files you created
4. Tapping the **(-)minus** button again it will take you back to the music files.
5. To Play the next file press the **(+)** button
6. To **DELETE** the recording press and **HOLD** the **(+)** AND **(-)** button while the audio file your wanting to delete is being played
7. The LED light should then start blinking rapidly
8. Press the **(+)** button to confirm deletion of the file and the device will begin to play the nest audio file
9. The previous audio file is now deleted
10. Turn the switch to **OFF** when done

How to **Delete the files** on a **PC**:



1. Open the **RECORD** folder
2. Open the **VOICE** folder
3. Right Click on the file you wish to delete and select Delete in the pop up menu

How to **Delete the files** on a **MAC**:



1. Open the **RECORD** folder
2. Open the **VOICE** folder
3. Click and **DRAG** the file you wish to delete to the Trash Bin
4. Empty the Trash Bin to permanently delete the file from the device.

Note: If the above step is not completed the files will not be fully deleted from the device and you will have a phantom folder that will contain the deleted files that can only be seen by a Windows Computer

How to **set Time/Date stamp**: Windows only



1. Connect the device to the USB port of the computer
2. Double click the **zipped SETTIME** folder
3. A default option will open to extract the zipped file
4. Inside the zipped file is another **SETTIME** folder
5. **Right Click** with your mouse on that folder and select **COPY** from the popup list and close
6. Go back to the **ROOT** folder where the **zipped SETTIME** folder as well as the **RECORD** folder is
7. **Right Click** and choose **PASTE** from the popup menu to place the **SETTIME** folder next to the **zipped SETTIME** and **RECORD** folder

NOTE: if a copy popup is not available choose "COPY TO..." from the list highlight the DRIVE named VOICE on the browser list

8. Click the unzipped **SETTIME** folder
9. Click the SetDigitRecorderTm . Exe file
10. The **SETUDISK TIME** Creator will open and Press **SET TIME** to sync the date/time with the PC
11. A pop up will occur indication success on setting up a time/date
12. Disconnect the device from the PC and create a new recording in order to sync the date and time
13. Reconnect the device to a PC and if **date/time** and now a time and date will be listed under the Date Modified tab

NOTE: Date and time setup can only be done on a Windows based PC

Specifications:

- MAX Memory capacity: 8GB
- Recording format: .WAV
- Recording capacity: @90 hours
- Battery power consumption: @16hours (continuous) @12hours (in playback)

VLC Media Player (recommended for optimal usage)How to **download** and use **VLC media (Windows)**

- www.videolan.org
- Click the Blue “download VLC”
- It will open a new window and begin downloading
- If it does not automatically begin downloading, press the Click here and select one of the mirrored sites
- Once downloading has completed select Run and install
- Once finished a VLC icon will now be available on your PC
- To default open a file in VLC media player, right click on the file you wish to open and select “open with” and choose VLC
- To change all files to default open with VLC media player: Right click and choose properties then click on the “Change” button next to “open with” and change it to VLC and press OK. Now the files will default open with VLC

How to **download VLC media (Mac)**

- www.videolan.org
- Click the Blue “download VLC”
- It will open a new window and begin downloading
- If it does not automatically begin downloading, press the Click here and select one of the mirrored sites
- Once completed a new file named VLC will be visible on the desktop
- Open the folder and in the folder move the VLC to the applications folder by drag and drop
- Once in the application folder the VLC player will complete the installation
- Open VLC media player in the Applications folder and simply drag your video files to the “drag here” dialog box to open and play
- If the VLC player is not installing a change to the Security and privacy settings is needed
- To access your Security and Privacy click on the Apple Icon on the task bar and select “system preferences”
- Select “security and privacy”
- Make sure the Lock icon on the bottom of the screen is open and set to Make Changes
- Select the button “Open Anyways”
- VLC will now fully install

NOTE: If a folder does not automatically open when connected to PC, disconnect the device and perform the following



WRISTBAND AUDIO RECORDER QUICK START GUIDE

SpyCentre.com Spy Shop - Since 1993

Toll Free # 1-800-292-7748



1. Open Control Panel by typing “control panel” in the Search bar
2. Select Programs
3. Under Default Programs, Click “Change default settings for media or devices”
4. Under Removable Devices, select “Open folder to view files”
5. Save
6. Reconnect the device to the PC

Monday - Saturday 10AM to 6PM CST