

Customer Service: (803) 591-9500
(M-F 9:00 am - 5:00 pm Eastern Time)

- Do not use an appliance for other than intended use.
- Always unplug an appliance from an outlet when not in use, as heaters, reflectors, lamp bulbs, etc.
- To avoid injury, do not contact moving parts or hot parts such as heaters, reflectors, lamp bulbs, etc.
- Always unplug an appliance from an outlet when not in use, as heaters, reflectors, lamp bulbs, etc.
- Do not use an appliance for other than intended use.

Close supervision is necessary when any appliance is used by or near children.

To avoid injury, do not contact moving parts or hot parts such as heaters, reflectors, lamp bulbs, etc.

Always unplug an appliance from an outlet when not in use, as heaters, reflectors, lamp bulbs, etc.

Before putting on or taking off parts, and before cleaning, Never yank cord to pull plug from outlet. Grasp the plug and pull to disconnect.

Presence of water in the receptacle.

Supplies power to the appliance. Then unplug and examine for DON'T unplug the cord. Disconnect the fuse or circuit breaker that in contact with the receptacle. If the plug or receptacle does get wet, cord is used, to prevent water travelling along the cord and coming below the level of the receptacle or the connector if an extension appliance to a receptacle. The "drip loop" is that part of the cord for each cord connecting an aquarium.

"loop" should be arranged by the user onto the receptacle or plug. A "drip" appliance to prevent water from dripping onto one side of a wall mounted receptacle to prevent water from dripping to one side of a wall mounted receptacle, position aquarium stand and tank wet, position aquarium stand and tank appliance plug or receptacle getting D. To avoid the possibility of the dropped or damaged in any manner.

Do not operate any appliance if it has a damaged cord or plug, it is malfunctioning or if it is plugged in if there is water on parts not intended to be wet. Be plugged in if there is water on parts not intended to be wet.

Carefully examine the appliance after installation. It should not be plugged in if there is water on parts not intended to be wet.

Do not operate any appliance if it has a damaged cord or plug, it is malfunctioning or if it is dropped or damaged in any manner.

WARNING: To guard against injury, basic safety precautions should be observed, including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

ANGER: To avoid possible electric shock, special care should be taken in the use of aquarium equipment. For each of the following situations, do not attempt repairs yourself. Return the appliance to an authorized service facility for service or discard the appliance.

IMPORTANT SAFEGUARDS



- Compact aquarium heater for small aquariums
- Fully submersible
- Shatterproof

www.cobaltaquatics.com

LIMITED 3-YEAR WARRANTY

Within three years from the date of original purchase, Cobalt Aquatics will repair or replace, at its option, any Mini-Therm heater which is deemed defective in workmanship or materials. Please return the unit, together with proof of date of purchase: Call 803-591-9500 for return authorization and shipping address.

NOTE: Be certain to wrap heater carefully for protection during shipment. Consumer will bear cost of shipping following completion of service. If the problem is not covered under the terms and conditions of this warranty, the consumer will be notified and given an estimate of repair charges (with all shipping charges billed to consumer). If the estimate is refused, the product will be returned freight collect.


Damage or injuries resulting from negligence or misuse are not covered by this warranty. Incidental or consequential damages are specifically excluded. This warranty gives you specific legal rights. You may also have other rights which vary from state to state. *Because some states do not allow the exclusion of incidental or consequential damages, this exclusion may not apply to you.

Questions or Missing Parts:
Call Customer Service at
803-591-9500
(M-F 9-5EST)

04/2012

ITEM NO.	DESCRIPTION
P0511	Suction Cups, 4 pack
P0516	Bracket w/ 4 Suction Cups

Replacement Parts List



- Never disassemble, tamper with, or try to repair your heater.

Never touch the component housing when heater is in operation.

Always keep cords dry and outside of the aquarium.

Always maintain the indicated minimum water level.

Always disconnect the heater before performing water changes.

Always allow your Mini-Therm to cool for at least 15 minutes after unplugging and before removal from water.

Never operate heater with bottom of heater exposed to air.

ADDITIONAL SAFETY CONSIDERATIONS

SAVE THESE INSTRUCTIONS

- Do not install or store the appliance where it will be exposed to the weather or to temperatures below freezing.
- Make sure an appliance mounted on a tank is securely installed before operating it.
- Read and observe all the important notices on the appliance.
- If an extension cord is necessary, a cord with a proper rating should be used. A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
- This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

MESURES DE SÉCURITÉ SUPPLÉMENTAIRES

- Ne jamais démonter, altérer ni tenter de réparer la chauffeurette.
- Ne jamais toucher au boîtier des composantes pendant le fonctionnement de la chauffeurette.
- Toujours garder les cordons secs et à l'extérieur de l'aquarium.
- Toujours maintenir le niveau d'eau minimal indiqué.
- Toujours débrancher la chauffeurette avant d'effectuer des changements d'eau.
- Toujours laisser la chauffeurette Mini-Therm refroidir pendant au moins 15 minutes après l'avoir débranchée avant d'enlever de l'eau.



GARANTIE LIMITÉE DE 3 ANS

CDans les trois ans à compter de la date d'achat originale. Elle ne peut pas être cédée ni transférée à tout acheteur ou utilisateur subséquent. À tout moment à compter de la date d'achat originale, Cobalt Aquatics réparera ou remplacera, à son choix, toute chauffeurette d'aquarium Mini-Therm qui présente un défaut de fabrication ou de matières premières. Veuillez appeler au (803) 591-9500 pour obtenir l'autorisation de retourner le produit ainsi que l'adresse d'expédition.

REMARQUE : S'assurer de bien envelopper la chauffeurette pour la protéger pendant le transport. Le client est responsable des frais d'expédition après la réparation. Si le problème n'est pas couvert en vertu des modalités et conditions de la présente garantie, le client en sera informé et recevra une estimation des frais de réparation (tous les frais d'expédition étant facturés au client). Si le client refuse l'estimation, le produit sera retourné fret payable à l'arrivée. Les dommages, bris de verre ou blessures qui résultent d'une négligence ou d'une utilisation abusive ne sont pas couverts par cette garantie. La perte de poissons, les blessures et les pertes et dommages matériels qui découlent de l'utilisation de cette chauffeurette ne sont pas couverts par cette garantie. Les dommages accessoires ou indirects sont expressément exclus*. Cette garantie vous confère des droits spécifiques. Vous pouvez également jouir d'autres droits qui varient selon votre lieu de résidence.

*Étant donné que certains États ne permettent pas l'exclusion des dommages accessoires ou indirects, cette exclusion peut ne pas s'appliquer dans votre cas.

WARNING:
NEVER operate Mini-Therm Heater outside of the filled aquarium. ALWAYS unplug appliance when inspecting for any reason.

Customer Service: (803) 591-9500
(M-F 9:00 am - 5:00 pm Eastern Time)

- Attach the suction cups (included) to the Mounting bracket. Slide bracket over heater to position indicated.
- Place heater in aquarium by firmly pressing suction ends against wall surface. Choose an algae-free location with adequate circulation. This ensures even heat distribution and optimum operation. No part of the heater housing should contact aquarium gravel, rocks or decorations.
- Wait at least 15 minutes before plugging in your heater.
- NOTE: Before plugging in heater, create a "drip loop" to prevent water from reaching receptacle and once plugged in will heat continually. Use selection guide on box to ensure you have the right heater for your aquarium. Periodically monitor water temperatures over next 48 hours to ensure proper temperatures are maintained.

IMPORTANT: Do not plug in heater until instructed.

DIRECTIONS

MEDIDAS DE SEGURIDAD ADICIONALES

- Nunca desarme, manipule ni intente reparar su calentador.
- Nunca toque el soporte del dispositivo cuando el calentador esté funcionando.
- Siempre mantenga los cables secos y fuera de la pecera.
- Siempre mantenga el nivel mínimo de agua indicado.
- Siempre desconecte el calentador antes de realizar cambios de agua.
- Siempre deje que su calentador Mini-Therm se enfríe al menos durante 15 minutos después de desconectarlo y antes de quitarlo del agua.



GARANTÍA LIMITADA DE 3 AÑOS

Dentro de tres años a partir de la fecha de compra original. La garantía no puede ser asignada ni transferida a ningún otro comprador o usuario posterior. En cualquier momento a partir de la fecha de compra, Cobalt Aquatics reparará o reemplazará, a su discreción, los calentadores de pecera Mini-Therm con defectos en la fabricación o los materiales. Llamar al (803) 591-9500 para obtener una autorización de devolución y una dirección para el envío.

NOTA: Asegúrese de envolver el calentador con cuidado para protegerlo durante el envío. El consumidor pagará el costo del envío luego de la reparación. Si el problema no está cubierto por los términos y condiciones de esta garantía, se avisará al consumidor y se le dará un presupuesto de los costos de reparación (con todos los costos de envío a cargo del consumidor). Si el presupuesto no es aceptado, el producto será devuelto con los costos de transporte por cobrar. Los daños, la rotura de vidrios y las lesiones que sean consecuencia de la negligencia o uso incorrecto no están cubiertos por esta garantía. La pérdida de peces, las lesiones personales, la pérdida de bienes o los daños que resulten del uso de este calentador no están cubiertos por esta garantía. Están específicamente excluidos los daños incidentales o a consecuencia de*. Esta garantía le otorga derechos legales específicos. Usted también puede tener otros derechos que varían de un estado a otro.

*Debido a que algunos estados no permiten la exclusión de los daños incidentales o consecuenciales, es posible que esta exclusión no se aplique en su caso.