

CHAINS & BINDERS,
CAM BUCKLE STRAPS,
SLINGS, HARDWARE,
RATCHET STRAPS,
SAFETY PRODUCTS,
WEBBING

RATCHETSTRAP.COM

PO Box 213, Coppell, TX 75019
1-844-678-7277
SALES@RATCHETSTRAP.COM

Auto Hauling, Boating,
Contractor, Equipment
Rental, Flatbed,
Interior Van, Motorcycle,
Oil Field, Roofing,
Recreation,
Tent Straps, Towing,
Wheelchair

Spa Cover Latch Set

- 4 Locking Latch Bodies (Female Component)
- 4 Strap Buckles (Pinch Release Clip – Male Component)
- 4 Strap Adjusters (not included with all kits)
- Keys
- Marine Grade 316 Stainless Steel Screws



INSTRUCTIONS: Strap Buckles If existing strap buckles are serviceable and of the same type as supplied in this kit, they may be reused. If existing buckles are broken, follow steps below for replacement.

1. Remove broken buckles from spa cover straps. Cut buckles with snips for removal, if necessary.



2. Replace strap buckles. Snip out a 1/8" section from strap buckle as shown below to facilitate a strap slot for installation of replacement buckles, without the need for cutting and re-sewing the straps.



3. Carefully slide strap material through the cut slot.



Locking Latches

1. Position and center the spa cover on spa.
2. Position locking latches on spa sides in locations corresponding to the spa straps. Allow about 1/2" to 3/4" slack in straps for ease of latching and removal.
3. Attach latch bodies with (2-3 a minimum included) screws. (For tile or concrete installations, use appropriate anchors and/or epoxy to secure screws). Pre-drilling of screw holes and hand installation is optimal.

Keep cover straps fastened when spa is not in use. For added security, latches may be locked with supplied keys.