




ADJUSTABLE TARP AND TENT POLE INSTRUCTIONS



Our adjustable tarp and tent poles provide unlimited flexibility in their assembly, allowing you to easily achieve your desired length. Each pole is made up from 5 sections.

- **Section 1** - The topmost section has a metal spike used to attach tarp grommets or guy lines.
- **Section 2** - The second section from the top has a total of 5 adjustment holes to refine the position of the topmost section.
- **Section 3** - The middle section includes a locking button at the top and a button opening at the bottom.
- **Section 4** - The second lowest section include a locking button at the top and several button openings at the bottom.
- **Section 5** - The lowest section has a rubber foot for grip and stability.

To achieve the full length of **72 inches**, assemble all five sections in the order described above.

To achieve the minimum length of **32 inches**, assembly only sections 1, 2, and 5.

To achieve shorter lengths, assemble sections 1 and 2 only, bypassing the rubber foot. This allows for a minimum length of only 18 inches. However, we recommend that you exercise care with the bottom of section 2 to not damage it on rocky surfaces.

To achieve a length longer than 72 inches for one pole, combine sections 3 and 4 from both poles and then add sections 1, 2, and 5.

If you have any further questions on assembly, please contact us at support@pariaoutdoorproducts.com.