




User Manual

FLASHLIGHT
DL5417/DL5418



GB Operating Instructions

SAFETY INSTRUCTIONS:

1. Read the operating instructions carefully prior to use.
2. Do not use the torch if it is damaged.
Please contact an electrician or write to the service address provided.
3. Do not look directly into the light.
4. Do not use the flashlight in an explosive environment as this poses a fatal risk!
5. Only use a certified USB source to charge the batteries.

OPERATION:

1. Drain the battery completely and recharge before using the lamp for the first time.
2. Possible modes of operation
 - Push the switch: 100% - off- 40% - off- SOS - off
 - Soft-touch function by tpping the switch: 100% (push) - 40% - SOS - off (push).
3. The flashlight CANNOT be used while charging.
4. Charging indicator: red during charging, green when the battery is charged.
5. If the lamp is not used for an extended period of time, it is recommended that the battery be charged every 3 months.

CHARGING:

Only charge your battery using a USB charging cable. Exclusively use a certified USB power source (e.g. charging device, computer) with a maximum of 5

V output voltage:

Connection: USB source - USB charging cable-charging socket

During the charging process, the product is not IP67-compliant (dust tight and protected against temporary immersion in water)

TECHNICAL SPECIFICATIONS:

LED: CREE-LED

USB charging input: 5 V/1 A (micro USB)

Flux: 200 lm

Charging time: ~3hrs

Battery: YK ICR 18650 dual pole 3.7 V/1.2 Ah

Protection class: IP 67

Temperature range: -20°C- +50°C

DECLARATION OF CONFORMITY

The declaration of conformity is stored at the manufacturers.

Do not dispose of electrical appliances, batteries and rechargeable batteries with your household rubbish.



Waste electrical and electronic devices, batteries and rechargeable batteries are classified as hazardous waste.

They must be collected separately from general waste to be recycled in an environmentally compatible manner.