60mm

Active Noise-Canceling Wireless Dartpods+

USER MANUAL



In the Box








Introduction to Parts





- 1. Touch button
- 2. Earbuds indication light

Safety Information

property or cause injury.

- 3. Microphone
- 4. Earbuds charging connectors
- 5. L mark
- 6. R mark
- 7. Battery indicator
- 8. USB-Ć charging port
- areas. Check and obey the applicable laws and regulations on the use of headphones and earphones while operating a vehicle.

 Use a standard charger only to charge the earphones

The use of noise-canceling earbuds while operating a

vehicle is not recommended and is illegal in some

- Use a standard charger only to charge the earphones to avoid damaging the battery.
- Frequent charging may reduce the battery performance.
- Do not expose the earbuds to direct heat.
- Keep the charging ports and earbuds clean.
- Do not dismantle the product.
- Do not clean the product with oil or any corrosive cleaning agents.
- Do not use the product in any potentially hazardous places.

Active Noise-Canceling

The Dartpods+ is equipped with active noise-canceling (ANC) to cancel the noise from your surroundings or allow you to hear and speak to people while wearing the earbuds. To switch between different ANC modes, press the touch button for 3 seconds and a voice feedback will be heard from the earbuds for the corresponding mode.

Pairing

For first use, insert the earbuds into the charging case, open the charging case and search for "Dartpods+" from the Bluetooth menu of your mobile device.

DW DARTWOOD

Once paired, the earbuds will connect to your device automatically when opening the charging case.

- 3. Tap the touch button three times to increase the volume (left) or reduce the volume (right).
- 4. Tap and hold the touch button for about 2 seconds to activate voice control and Siri.
- 5. Tap and hold the touch button for about 3 seconds to activate/ cancel the active noise-canceling (ANC).
- 6. Tap and hold the touch button for about 5 seconds to turn the earbuds power on/ off.

Specifications

Model: Dartpods+
Color: Black / white

Bluetooth version: 5.2
Driver size: 10mm graphene speaker

Read and follow the instructions carefully.

cause permanent hearing damage.

Prolonged exposure to high volume levels could

Do not attempt to replace earbuds or charging case

batteries yourself. It can cause damage to your

Music play time: Approx. 6hr, 30hr with charging case

Earbuds charging time: Approx. 1hr
Charging input: 5V 1A
Connection distance: 49ft (15m)
Noise reduction: 33 - 38dB

Earbud dimension: 0.91 x 1.21 x 0.66in Charging case dimension: 1.93 x 2.32 x 0.94in

Net weight: 1.6oz

* The actual product and specifications are subject to change without notice due to product enhancement.

* Battery life and charge cycles may vary depending on your settings and actual environment factors.

Get More Support

Scan the QR code below or email us at contact@wasserstein-home.com.





Touch Control



- 1. Tap the touch button once to answer an incoming call, hang up the call, and play/ pause the music.
- Tap the touch button twice to play the previous song (left) or skip songs (right).

Charging

- Fully charge the earbuds before using them for the first time.
- Insert the earbuds into the charging case. Make sure to place the correct earbud to the corresponding dock.
- Close the charging case cover to charge the earbuds. It takes around 1 hr to fully charge the earbuds.
- 4. To charge the charging case, connect it with the cable provided to a power source.
- 5. The battery indicator will show the progress during charge, all indicators will turn off once fully charged.

DW DARTWOOD

r more information, please visit: rww.wasserstein-home.com Made in China

70mm