

Screen Protector for Fitbit Sense, Versa 3, and Versa 4


User Manual



W
WASSERSTEIN

MADE FOR
 fitbit

In the Box



3 x screen protectors



3 x wet wipes



3 x dry wipes



1 x sticker ring




1 x card

How to Install

Watch the video tutorial before use.



1. Remove the covers of the sticker ring and stick it firmly on the table.





2. Place your Fitbit on the sticker ring (it's easier if you remove the Fitbit straps first).




3. First, use the wet wipe to clean your Fitbit screen. Next, use the dry wipe to clean any dust that may remain.




4. Peel off layer 1 from the screen protector and place it on your Fitbit screen. Use the cloth side of the card provided to squeeze out any air bubbles.




5. Hold the bottom of the screen protector with the card and remove layer 2. Squeeze out any air bubbles.



6. Remove layer 3 and squeeze out any air bubbles.



7. Remove layer 4 and you are finished.



Specifications

Compatible model: Fitbit Sense, Versa 3, and Versa 4

Material: TPU

Dimension: 1.42 x 1.42 x 0.003 in

Get More Support

Scan the QR code below or email us at:
contact@wasserstein-home.com



This product has been certified by Wasserstein to meet Fitbit's compatibility standards. Neither Google nor Fitbit is responsible for the operation of this product or its compliance with any applicable safety or other requirements. Learn more at g.co/madeforgoogle.

Google's "Made for" badges, Fitbit Sense, Versa 3, Versa 4, and related marks and logos are trademarks of Google LLC.

Fitbit Sense, Versa 3, and Versa 4 is not included.
Fitbit Sense, Versa 3, and Versa 4 is a trademark of Fitbit.
Wasserstein is not affiliated with Fitbit.
Wasserstein is a trademark of Dropcases Ltd.

W
WASSERSTEIN
www.wasserstein-home.com

Made in China