

### In the Box



#### Warninas


- Do not overcharge or over-discharge the product, it may shorten the battery life of the product.
- Avoid any foreign object into the fan while it is on
- The product can be used by children under the age of 14 under adult supervision.
- Do not squeeze, disassemble the battery, or leave the battery in a high-temperature environment (60°C or above) for a long period. Otherwise, it may cause damage, and risk of leakage or explosion.
- Do not use this product while charging.
- The battery must not be disassembled, hit, squeezed, or thrown into the fire.

Page 1

# Safety Precautions

- Do not place your hair too close to the air inlet while using.
- Never open or bend the flexible neck with excessive force to avoid damage to the product.

#### Introduction to Parts




- 1. Air Inlet
- 2. Air Outlet
- 3. Flexible Neck
- 4. Type-C Charging Port
- 5. Power Button
- 6. Indicator

Page 2

### How to Use

1. Charge the portable neck fan before use, the LED indicator will turn off when fully charged.



2. Place the neck fan around your neck with the air outlet facing upwards.

Page 3

On/ Level 1

3. Press the power button to switch between

4. When the battery is running low, the LED

indicator will flash. Recharge it immediately.

5. Charge the product after use and store it in

OFF

different modes.

a cool, dry place.

Wind Speed .

Level 2 Wind

Page 4

# Cleaning and Maintenance

- 1. Turn off the power before cleaning the product.
- 2. Wipe the body with a dry, damp cloth.
- 3. Never clean the product and its electrical parts (such as motors, power switches, etc.) with water or other liquids.
- 4. Regularly remove dust or foreign objects from the air outlet

Scan the OR code below or, email us at

contact@wasserstein-home.com

Get More Support

# **Specifications**

Page 5

4000 mAh **Battery Capacity** Battery type: Lithium-ion Battery DC 5.0V Input: Fan Power: 5W (Max.) Fan Speed: Up to 2 m/s Charging Time: Approx. 4 hrs Working Time: 4 - 16 hrs Size: 8.6 x 6.7 x 2.4 in Weight: 0.62 lb

**DW** DARTWOOD

For more information, please visit: www.wasserstein-home.com

100mm