

Floodlight For Google Nest Cam (battery)

USER MANUAL



W
WASSERSTEIN


made for
Google Nest

Before installing this accessory, please first set up the Google Nest Cam (battery) using the in-box cable provided with the camera. This will ensure that you have the latest firmware. 

Product Highlights

- 3-in-1 Floodlight, Charger and Mount.
- The Wasserstein Floodlight gets triggered in the presence of motion at night.
- Its PIR Motion Detection range is between 13 to 33 ft.
- The Wasserstein Floodlight lights up for 30 seconds after detecting motion at night.
- For optimum results, we recommend mounting the floodlight on walls at a high vantage point. The motion sensor works best when movements are detected parallel to the floodlight, not towards it.

In the Box

- 1 x floodlight
- 2 x screws
- 2 x small screws
- 1 x crossbar
- 1 x screw cap
- 3 x wire nuts
- 1 x EVA gasket
- 1 x user manual




Installation

Pre-installation


Note: If you are unfamiliar with electrical installations, we highly recommend hiring a professional electrician to perform the installation.

1. Make sure that you have all the included materials.
2. You will be working with electrical wires during the installation process. For safety reasons, shut off the power to your floodlight at the circuit breaker.




If you have an existing Floodlight


1. Remove your existing floodlight from the junction box it is attached to, and disconnect the wires.



2. Remove the crossbar attached to your junction box.




2. Remove the protective tape from the EVA gasket. Press the adhesive side firmly against the rear of the floodlight.




Installing the Floodlight to the Junction Box

1. Attach the crossbar included in the package to the junction box with the screws.




3. Ensure that the center screw hole and wire slot of the foam gasket are aligned with the screw hole and wire slot.



Wiring the Floodlight and Junction Box through the EVA Gasket

The white wire on your floodlight is a neutral wire.
The black wire on your floodlight is a hot wire.


1. Connect the green and yellow wire from the floodlight to the existing ground wire inside the junction box. Use the included wire nut to connect the wires properly.
2. Using a wire nut, connect the white neutral wire from the floodlight to the neutral wire of the junction box.
3. Using a wire nut, connect the black hot wire from the floodlight to the hot wire of the junction box.




4. Make sure that the wire connections are secured. Carefully place the wires into the junction box.

Important:

Before mounting the floodlight, completely apply the EVA gasket around the perimeter of the cover plate where the back of the cover plate meets the mounting surface. This prevents water from seeping into the junction box.




5. Mount the floodlight onto the crossbar and secure it with the screw cap provided.





6. Switch on the electricity, checking that the wiring has been done correctly and that the floodlight illuminates.

Mounting Your Camera


1. To charge your camera via the floodlight, please install the camera wall plate onto the floodlight.
2. Install the Nest Cam wall plate on the floodlight using the two short screws included. Screw in tightly.



3. Attach the magnetic plate onto the wall plate and turn it clockwise to lock it in place




4. Attach the camera to the mount, and connect the charging connector to the camera to charge it.



Note:


Make sure that the connector is connected in the right direction as shown in the picture.




5. Adjust your Nest Cam to your preferred viewing angle. You may use the video streaming feature in the Nest app to fine-tune your camera's position.

Mounting Your Camera along with the Anti-Theft Mount



1. Place the security chain underneath the wall plate of the camera behind the screw hole.




2. Screw in the wall plate tightly using the two short screws provided.




3. "Attach the magnetic plate onto the wall plate, and turn it clockwise to lock it in place."




4. Slide in the anti-theft mount on the camera, make sure to align the speaker/cable opening at the bottom.



5. Make sure that the end of the security chain with the small hole goes in between the screw holes of the mount. Use the hexagon screwdriver to tighten the mount and lock the security chain.



7. Attach the camera to the floodlight with the magnetic mount and connect the magnetic connector to it.



Checking the Power Status via Your Nest App

The floodlight continuously powers your Google Nest Cam (battery).
The ∞ sign will be displayed in the Google Home App.

FAQ

The floodlight keeps flashing. What should I do?

- Check your connection of all three wires to the house power.
- Check the area around the floodlight as it may be detecting motion.

The floodlight will not turn on. What should I do?

- Make sure you are testing the floodlight in darkness.
- Check your connection to the house power.
- Leave the area for 10 minutes to give time for the floodlight to reset without triggering it. Return and check the floodlight by turning off the power for at least a minute, then turning it back on.

How bright is the floodlight?

- The floodlight has a maximum LED light intensity of 2400 lumens.

Will the floodlight turn on during the day?

- No, the floodlight will only turn on during the night or when the surrounding light is dim.

Safety Information

- Disassembling the floodlight is not recommended as it may cause damage to internal components. The floodlight may not function properly after disassembly.
- Turn the main circuit OFF before installation.
- Do NOT remove the protective LED lens.
- Do NOT look directly at LEDs that are turned on for any length of time.
- Do NOT leave bare wires exposed outside the wall canopy enclosure.

This product has been certified by Wasserstein to meet Google's compatibility standards. Google is not responsible for the operation of this product or its compliance with any applicable safety or other requirements.

Learn more at g.co/madeforgoogle.

Google's "made for" badge, Google Nest Cam, and related marks are trademarks of Google LLC.



Google Nest Cam (battery) is not included.
Wasserstein is not affiliated with Google LLC.
Wasserstein is a trademark of Dropcases Ltd.
Google Nest Cam is a trademark of Google LLC.

For more information, visit:
www.wasserstein-home.com
or contact us at:
contact@wasserstein-home.com
Made in China