Solar Power Bank

User Manual





In the Box

- 1 x Solar Power Bank 1 x Charging Cable
- 1 x User Manual



Features



Waterproof, shockproof,

and dustproof.

Charge up to 3 devices

Page 2

simultaneously. USB Output 1 & 2

Introduction to Parts

Micro-USB Input

. Flashlight

Power Button

Wireless Output

Solar Panel

Type-C Input/Output . Power Indicator

. Solar Charging Indicator



4 multi-functional LED lights.

short-circuit, over-charge

Equipped with

Compatibility

devices.

Compatible with smartphones and all compatible


Safety Information

• When needed, discard the device properly.

- If the device is not being used for an extended period, please charge it at least every 6 months.
- Keep the device dry and do not clean it with
- Keep the device away from heat source.
- Children may use the device only with adult
- Do not crash, disassemble or impale the
- Do not use the product to charge incompatible devices. Incompatible voltage and current may explode the device, cause fire or other problems.

Operational Instructions

To charge your device Place your device to the wireless charger and





the USB output or Type-C port.



To check battery status Alternatively, connect the charging cable to

. Press the power button once to check the solar power status.

Press the power button to start charging.



Check the remaining power of the power bank from the power indicators.

> One BLUE light is on The power is within 25%. Two BLUE lights are on The power is within 50%. Three BLUE lights are on The power is within 75%. Four BLUE lights are on The power is within 100%.

To charge the power bank

Place the solar panel in direct sunlight.



. Solar charging indicator will turn green when being charged using the solar panel.



Alternatively, connect the power bank with


Micro USB or Type-C charging cable. The 4 power indicators will show solid blue when the power bank is fully charged.

Page 8



To turn on/off the flashlight

- Double click the power button to turn on the Please refer to the operational instruction for
- Caution: The Flashlight contains bright LEDs, any other troubleshooting.



3. Double click to turn off the flashlight.

- switched on.

www.wasserstein-home.com

• Make sure that it has enough battery left

: 16,000 mAh

: DC 5V 2A Max.

: DC 5V 3A Max.

: 7 x 3.4 x 8.3 in

: 32°F - 113°F

: 1.8 W

: 5W Max.

: 4 x 0.5 W

to charge your phone.

Capacity

Flashlight Product size

Solar charger power

Wireless charger output

Charging input

Charging output

Product net weight

Working temperature

contact@wasserstein-home.com Made in China

Page 4

Page 6

never point it to the eyes. 2. Click once to switch the light pattern. Product Specifications



Troubleshooting

- If the power bank does not charge your
- Make sure that the device being charged is compatible.
- Make sure that the power bank is

Page 9

For more information, please visit: or contact us at:

*Specifications are subject to change without notice or

