# Spotlight Kit for Blink Outdoor and Indoor Camera

**USER MANUAL** 






## In the Box




#### How to Install

Note: Fully charge the spotlight before using.

 Make sure the labels on the back of the spotlight are right-side-up, and slide the spotlight into the top of the rubber casing.




Make sure the Blink logo on the front and labels on the back of the Blink Cam are right-side-up, and slide the Blink Cam into the bottom of the rubber casing.




3. Plug the split USB adapter cable into both the spotlight and Blink Cam USB ports.




4. Plug the USB cable into the split USB adapter cable.



 To turn on/off, flip the switch on the left side. Flip left for ON, right for AUTO.



5. To adjust the timer, flip the switch on the right side: 30 seconds, 1 minute, or 5 minutes.



### Specifications

Lumens: 100 lumens Angle: 120 degrees

Power supply: 5V 1A
Dimension: 1 x 2.2 x 1.4 in
Connection: micro USB

Connection: micro USB
Operating current: 130 -150mA
Motion sensing distance: 6.6 -16.4 ft
Standby current: 2mA

Battery life: 2-3 days Number of LEDs: 8

Light temperature: 4000K

Operating conditions: -4 °F to 131 °F (-20 °C to 55 °C)

## Get More Support

Scan the QR code below or email us at contact@wasserstein-home.com.



Blink Outdoor Camera is not included.
Blink Indoor Camera is not included.
Wasserstein is a trademark of Dropcases Ltd.
Wasserstein is not affiliated with
Immedia Semiconductor, LLC.
Blink is the trademark of Immedia Semiconductor, LLC.



www.wasserstein-home.com

Made in China