
# USB Power Cable for Google Chromecast with Google TV

USER MANUAL





#### In the Box



### Safety Information

- Read these instructions carefully before use. Failure to follow the safety instructions may cause injury or damage to your property.
- Small parts contained in the box can be a choking hazard. Keep small parts away from children.
- Only use this cable with the Google Chromecast.

#### Setu

 Line up the USB port of your Chromecast with the Type-C connector, and gently slide the device into the slot.



- 2. Make sure the casing fully wraps around the outside of your Chromecast device.
- 3. Connect the HDMI cable with the HDMI port of your TV.



When connected, the device will turn on/off with your TV automatically.

Page 2

### Specifications

Color: White Material: ABS plastic

Battery capacity: 2,000 mAh

Input Power: 5V/500 mA

Output Power: 5V/1.8A

## Get More Support

Scan the QR code below or email us at contact@wasserstein-home.com.



CONTACT US

Google Chromecast is not included. Wasserstein is not affiliated with Google LLC. Wasserstein is a trademark of Dropcases Ltd. Google Chromecast is a trademark of Google LLC.

WASSERSTEIN
www.wasserstein-home.com