Wall Plate for Wyze Video Doorbell Pro

User Manual




W WASSERSTEIN

In the Box







Safety Information

- Read these instructions carefully before use.
 Failure to follow the safety instructions may cause injury and damage to your property.
- Small parts contained in the box can be a choking hazard. Keep small parts away from children.
- Only use this wall plate with the Wyze Video Doorbell Pro

Pre-Installation

1. Turn off the power of your existing video doorbell at the electrical panel.


Note: Always consult a professional electrician before working with electrical wires.



Remove your existing video doorbell (if any) from the wall.

Installation


 Place the doorbell backplate on top of the wall plate and screw them both onto the wall (drill size is 1/8 in).



2. If you have a wired doorbell, connect the wires first before securing it to the wall plate.



Turn on the doorbell. Hook the tabs at the back and press firmly on wall plate until it clicks into place.




4. Check the view from the App, then secure the doorbell with a screw at the bottom.




Installation with Angle Mount

1. Screw the wall plate and angle mount together onto the wall (drill size is 1/8 in).




 Screw the doorbell's backplate onto the angle mount using the original screws that come with the doorbell.



3. If you have a wired doorbell, connect the wires first before securing it to the wall plate.



4. Turn on the doorbell. Hook the tabs at the back and press firmly until it clicks into place.



5. Check the view from the App, then secure the doorbell with a screw at the bottom.



Specifications

Compatibility: Wyze Video Doorbell Pro Dimensions: 7.28 x 3.54 x 0.30 in

Get More Support

Scan the QR code below or email us at: contact@wasserstein-home.com



