## FANTASIA

Fantasy · Fantasía





FANTASIA Travessa 45 Platter 45 Fuente 45 A 35 mm C 450 mm L 265 mm H 1 %" L 17 %" W 10 %"

• 65004646 • 65019126 • 65002259 • 65016871 • 65019127 • 65013361



FANTASIA Prato Marcador 34 Charger Plate 34 Plato Presentación 34 A 30 mm C 340 mm L 340 mm H 1 1/6" L 13 3/5" W 13 3/5"

• 65011968 • 65019114 • 65002239 • 65017324 • 65019115 • 65011206



FANTASIA Prato Raso 29 Dinner Plate 29 Plato Llano 29 A 25 mm C 290 mm L 290 mm H 1" L 11 35" W 11 35"

● 65008471 ● 65019117 • 65002244 • 65017325 • 65019118 • 65011233 • 65019116



FANTASIA Prato Sobremesa 22 Dessert Plote 22 Plato Postre 22 A 28 mm C 220 mm L 220 mm H 1 1/9" L 8 3/9" W 8 3/9"

● 65004642 ● 65019119 ● 65002249 ● 65010618 ● 65019120 ● 65011199



FANTASIA Saladeira Pasta 35 Pasta Bowl 35 Ensaladera Pasta 35 H 2 1/4" L 13 7/4" W 13 7/4"

• 65004656 • 65019131 • 65002290 • 65017418 • 65019132 • 65011274 65019130



FANTASIA Saladeira 30 Salad Bowl 30 Ensaladera 30 A 105 mm C 300 mm L 300 mm Cap. 5000 ml H 4 1/4" L 11 1/4" W 11 1/4" Cap. 169 oz

● 65004654 ● 65019167 ● 65002285 ● 65017383 ● 65019168 ■ 65013362 65019166



FANTASIA Saladeira 23 Salad Bowl 23 Ensaladera 23 A 95 mm C 233 mm L 233 mm Cap. 2500 ml H 3 ¾" L 9 ½" W 9 ½" Cap. 84 ½ oz

• 65019291 • 65019295 • 65019294 • 65019290 • 65019296 • 65019292 65019293



FANTASIA Saladeira 21,5 Salad Bowl 21,5 Ensaladera 21,5 A 55 mm C 210 mm L 210 mm H 2 1/4" L 8 1/4" W 8 1/4"

• 65013525 • 65019123 • 65002254 • 65017417 • 65019124 • 65011277 65019121



FANTASIA

Tigela 14,5 Bowl 14,5 Bowl 14,5 A 76 mm C 145 mm L 145 mm H 3" L 5 %" W 5 %"

• 65016120 • 65019152 • 65015986 • 65016666 • 65019153 • 65015983 • 65016656



FANTASIA Tigela Arroz 12,5 Rice Bowl 12,5 Bowl Arroz 12,5 A 70 mm C 125 mm L 125 mm H 2 ¾" L 5" W 5"

• 65018815 • 65019160 • 65019159 • 65018816 • 65019161 • 65018817 • 65019158



FANTASIA Jarro 1,5L Pitcher 1,5L Jarra 1,5L A 195 mm C 190 mm L 160 mm Cap. 1500 ml H 7 ½" L 7 ½" W 6 ½" Cap. 50 ½ oz

• 65004650 • 65019128 • 65002280 • 65016551 • 65019129 • 65015505 • 65014356



FANTASIA Caneca Mug A 110 mm C 130 mm L 90 mm Cap. 500 ml H 4 ½" L 5 ½" W 3 ½" Cap. 17 oz

• 65018714 • 65019156 • 65019155 • 65018713 • 65019157 • 65018715





FANTASIA Bule Tea Pot Tetera

A 150 mm C 264 mm L 153 mm Cap. 1500 ml H 6" L 10 36" W 6" Cap. 50 ½ oz

• 65019258 • 65019262 • 65019261 • 65019236 • 65019263 • 65019259



H 3 ½" L 5 ½" W 4" Cap. 15 % oz • 65019270 • 65019274 • 65019273 • 65019238 • 65019275 • 65019271 • 65019272

A 90 mm C 135 mm L 100 mm Cap. 450 ml



FANTASIA

Leiteira

Milk Jug

Lechera

## FANTASIA Açucareiro Sugar Box Azucarero

A 110 mm C 105 mm L 105 mm Cap. 500 ml H 4 ½" L 4 ½" W 4 ½" Cap. 17 oz

● 65019264 ● 65019268 ● 65019267 ● 65019237 ● 65019269 ● 65019265





## FANTASIA Chávena Café com Pires Coffee Cup and Saucer Taza Café con Platillo

A 72 mm C 145 mm L 145 mm Cap. 150 ml H 2 %" L 5 %" W 5 %" Cap. 5 oz

● 65019246 ● 65019250 ● 65019249 ● 65019239 ● 65019251 ● 65019247





FANTASIA Chávena Chá com Pires Tea Cup and Saucer Taza Té con Platillo A 75 mm C 160 mm L160 mm Cap. 350 ml H 3" L 6 <sup>2</sup>/<sub>7</sub>" W 6 <sup>2</sup>/<sub>7</sub>" Cap. 11 % oz

• 65018931 • 65019149 • 65019148 • 65018930 • 65019150 • 65015573



FANTASIA Torteira Tart Tray Fuente Torta

A 29 mm C 475 mm L 186 mm H 1 ½" L 18 ½" W 7 ½"

• 65019252 • 65019256 • 65019255 • 65019253 • 65019254 • 65019253



FANTASIA Prato com Pé 34,5 Cake Stand 34,5 Plato con Pie 34,5

A 125 mm C 345 mm L 345 mm H 5" L 13 4/5" W 13 4/5"

• 65011972 • 65019136 • 65002315 • 65016550 • 65019137 • 65012029



Cake Stand 28 Plato con Pie 28 A 93 mm C 280 mm L 280 mm H 3 <sup>2</sup>/<sub>3</sub>" L 11" W 11"

• 65013069 • 65019139 • 65002320 • 65016549 • 65019140 • 65015511 • 65019138



FANTASIA Prato com Pé 22 Cake Stand 22

• 65004658 • 65019134 • 65002300 • 65017381 • 65019135 • 65013392 • 65019133















