
# **MANOS**

# Universal Tablet Holder QUICK START GUIDE

- Screw Manos Mount onto any standard mic stand thread and rotate so one arm is up and the other is down.
- Lightly loosen side knobs to release adjustable mount arms. Squeeze open the clamp on the lower arm and insert the tablet.
- Move the upper arm into place and clamp the other side of the tablet.
- Make sure the pivot feet and clamps are firmly contacting the tablet. Tighten the knobs to secure.
- Adjust swivel mount base 360° for optimal viewings.
- 6 Loosen pivot knob to adjust tilt.



Note: Do not remove side knobs as the springs will release. They are not user installable.

# MANOS Universal Tablet Holder

# **Tips and Tricks**

- · Always insert the tablet into the Manos with one arm down.
- Be sure device is snugly inserted with both clamps engaged and that the pivot feet are contacting the back of the device.
- Tighten the arm clamps every use for increased security.
- Heavier tablets in portrait mode should have more of the weight above the mount fingers.
- Return the Manos arms to the vertical position for device removal.
- · Loosen the arm clamps for removal.
- Remove the top side first.
- $\bullet$  You can store the Manos flat by opening all the way to engage the storage locks.  $\_$



#### **Pivot Feet**

The pivot feet will function differently on different size devices. For smaller devices such as phones and smaller tablets, the tablet will fit into the corners of the foot. Larger tablets and tablets with cases, both edges of the foot will contact the tablet.

# **Keep Your Case**

From smartphones to tablets, the Manos Mount can accommodate reading devices of all sizes. And keep your cover on – the Manos Mount can grip your device in or out of any protective case, even iPads in Otterboxes or Griffen Survivor.

# Easy In. Easy Out.

The AirTurn Manos Mount locks flat for easy transport in your gig bag. The spring-loaded finger clamps make it a breeze to mount or remove your device in a flash, and the locking screws make it simple to ensure the maximum protection for your tablet or smartphone.

- Rugged heavy-duty design.
- Holds smartphones and tablets from 5" to 13.3" with protective covering.
- Proprietary rubber coating on mount fingers for maximum grip on the widest range of surface materials and textures.
- Accommodates flat and rounded device and cover surfaces.
- Provides an unobstructed view of your device's screen, as well as an uncluttered view from behind.



## Warranty

Your AirTurn Manos comes with a one year warranty against defects in manufacturing. Register for an additional year at warranty.airturn.com. This warranty does not cover damage for any thing attached or inserted into the Manos. Please contact your dealer or AirTurn, Inc. for directions for repair or replacement.

## Important

Be sure to follow directions completely for inserting your device into the Manos. Check to be sure the pivot foot is securely contacting the back of your device. Tighten the knobs of the clamp arms to keep them snugly fit to your device during each use. DO NOT UNSCREW ARM KNOBS ALL THE WAY!

When mounting heavier tablets, be sure approximately 60% of the weight is above the Manos arms.

If the contact parts of the Manos become dusty, wipe clean with a damp cloth. This will insure the integrity of the natural stickiness for many years.

www.airturn.com support@airturn.com 888-247-1223 Boulder, CO 80301 Made in the U.S.A.