

Fiat Abarth Punto LED Upgrade Kit Fitting Tips

Headlights - when installing the headlights, make sure to make an incision into the rubber cover.

Remove the heatsink from the LED head unit by unscrewing it and fit the LED head unit into place and secure it with the spring clip. Screw the heatsink on by a couple of turns only.

Pass the LED H4 connector though the rubber cover (outside to inside) and plug the LED H4 connector into the headlight H4 connector and tuck it behind the heatsink. Then screw the heatsink tightly onto the LED.

Pass the lead from the LED head unit though the rubber cover (inside to outside) and connect it to the waterproof control unit (which will be outside the rubber cover). Both cables ends from the control unit should go inside the rubber cover (one end is to the LED head unit and other is to the H4 wiring connector) then refit the rubber cover to the light unit. Use a zip tie to attach the control unit to the wing support bracket (headlight support) to keep it from moving.



Sidelights - when installing, make sure to make an incision to the bottom of the rubber for the resistor to pass from and to the light fitting - do NOT place the resistor inside light as it can get very hot and will melt plastics. When installing the light, wrap electrical tape around the bulb holder that sits in the light - *trial fit the bulb holder before installing the LED as it can fall into the headlight if you are not careful. Make sure the fit is snug but not so tight that it won't come out again, install LED and fit to headlight.

Grande Front Fog Lights - some work is needed for these. Access from under the car, remove the under tray if on the car and take off the fog light caps. A hole has to be cut that is large enough for the LED to fit through. Once this has been done, put the LED through the hole in the cap, fit the LED to the fog light, fit the cap and connect the LED to the waterproof control unit. Two female connectors are needed to attach the vehicle wiring to the control unit. Zip tie the control unit to the fog light and refit under tray.

