

| Clearview Sub-Base Selection Guide | |
|---|--|
| SKU | Router Model Number |
| | |
| | 1/4" Trimmer |
| CVTR1 | Makita DRT50RMJX2, DRT50ZJ, DRT50ZJX3, DRT50ZX4, RT0700CX2, RT0700CX4 Katsu 101748, 101749, 101748G, 101749G Moss 1/4" 3/8 Hand Trimmer VonHaus 15/302 Compact Deluxe Zen 6+10mm Hand Trimmer |
| CVTR2 | DeWalt DWE6005 |
| CVTR3 | DeWalt D26200 |
| | |
| | 1/4" Plunge |
| CVPL1 | Makita DRT50RMJX2, DRT50ZJ, DRT50ZJX3, DRT50ZX4, RT0700CX2, RT0700CX4 Katsu 101748, 101749, 101748G, 101749G Moss 1/4" 3/8 Hand Trimmer VonHaus 15/302 Compact Deluxe Zen 6+10mm Hand Trimmer |
| CVPL2 | DeWalt DW620, 621, 624, 625EK, 629 Elu OF97(E), MOF131, MOF177(E) Bosch GOF1600A, 1700ACE Makita RP0910, 0111C Performance Pro (B&Q) CLM12050R, CLM2050R |
| CVPL3 | Trend T5v2 |
| CVPL4 | Festool OF 1010 EBQ (includes Festool and Whiteside Template Apertures) |
| CVPL5 | Ozito ROU-5000U |