



The Perfect Temperature

IN EVERY ROOM

Get to know us:
pros@flair.co
flair.co/pros



Flair Puck

FEATURES

- Monitors room temperature and controls Flair Smart Vents, mini splits, window ACs, and portables
- Control from your phone, tablet, or computer anywhere in the world
- Auto Away - saves energy when you are away
- Auto Dry Mode - maintains desired humidity levels
- Adjust the temperature by rotating the Puck - no smartphone required
- Infrared (IR) control for over 200 brands of mini splits, portables, and ACs
- Set weekly schedules on a room-by-room basis
- Puck Pro model has heat staging features that qualify mini split systems for rebates
- Wireless or wired installation options (first Puck must be wired)

SPECS

- E Ink display
- Wired power adapter
- 2 x AAA batteries (included)
- Temperature sensor
- 915 MHz low power radio
- 2.4 GHz Wi-Fi
- 4 year professional warranty
- Humidity sensor

INTEGRATIONS

				
				
				
			and more!	