



CONGRATULATIONS

You are the proud owner of a RINGERS  WESTERN watch.

For best results, please read the instructions carefully before using your new RINGERS  WESTERN watch.

1. FUNCTIONS & USES

TIME & DATE SETTING



- (1) Normal Position
- (2) First Click: Date Setting (anti-clockwise). For watches with day and date to set, turn clockwise.
- (3) Second Click: Time Setting

SCREW DOWN CROWN



Some watches have a screw down crown to ensure water resistance. You must unscrew the crown (counter-clockwise) to enable you to pull it out to set the time. After setting crown, always ensure you re-screw the crown to ensure water resistance.

2. MAINTENANCE

CARE OF CASE AND BRACELET

To prevent possible deterioration of the case and bracelet caused by dust, moisture and perspiration, wipe them periodically with dry soft cloth.

CHEMICALS

Be careful not to expose the watch to solvents (e.g. alcohol and gasoline), mercury (i.e. from a broken thermometer), cosmetic spray, detergents, adhesives or paints. Otherwise the case and bracelet etc., may become discoloured, deteriorated, or damaged.

MAGNETISM

Your watch will be adversely affected by strong magnetism. Keep it away from close contact with magnetic objects.

3. WATER RESISTANCE

A. Non-Water Resistant

If "WATER RESISTANT" or "SHOWER PROOF" is not inscribed on the case back, your watch is not water resistant or shower proof, and care should be taken not to get it wet as water may damage the movement.

B. Water Resistant or Shower Proof

If "WATER RESISTANT" or "SHOWER PROOF" is inscribed on the case back, your watch is designed and manufactured to withstand accidental contact with splashes of water or rain.

C. Water Resistant 3 Bar / 3ATM (30 metres)

If "WATER RESISTANT 3 BAR" or "3ATM" is inscribed on the case back, your watch is designed and manufactured to withstand 3 bar (30 metres). Even though you can swim or shower with this watch, we do not recommend that you do.

D. Water Resistant 5 Bar / 5ATM (50 metres)

If "WATER RESISTANT 5 BAR" or "5ATM" is inscribed on the case back, your watch is designed and manufactured to withstand 5 bar (50 metres), and is suitable for swimming and taking a shower.

E. Water Resistant 10 Bar / 10ATM (100 metres) and 20 Bar / 20ATM (200 metres), 50 Bar / 50ATM (500 metres)


If "WATER RESISTANT 10 BAR/ATM" or "WATER RESISTANT 20 BAR/ATM", or "WATER RESISTANT 50 BAR/ ATM" is inscribed on the case back, your watch is designed and manufactured to withstand up to 10 bar (100 metres)/ 20 bar (200 metres) / 50 bar (500 metres) and is suitable for diving and any other water contact.



4. WARRANTY

This watch is guaranteed to be free from defects in material and or workmanship under normal use for a period of two (2) years from the date of purchase. To obtain service under warranty the watch should be returned directly to the manufacturer along with your proof of purchase. Any cost incurred by you in returning the product to the manufacturer will be borne by you. We will, at our option, either repair or replace the product, or refund your money and take back the product.

Our goods come with guarantees that cannot be excluded under the Australian consumer law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The benefits conferred by the manufacturer's warranty are in addition to all rights and remedies conveyed by the Competition and Consumer Act 2010 (Commonwealth), and any other statutory rights to which you may already be entitled, and this warranty does not exclude, restrict or modify any such rights or remedies that are implied by law.

Your **RINGERS**  **WESTERN** watch is under warranty for a period of 24 months (2 years) from the date of purchase under the terms and conditions of this warranty.


The International **RINGERS**  **WESTERN** warranty covers materials and manufacturing defects. The warranty comes into force only if the warranty (International Guarantee) is fully and correctly stamped by an authorised **RINGERS**  **WESTERN** dealer.

The manufacturer's warranty does not cover:

- crystal, leather strap;
- damage resulting from improper handling, lack of care, accidents (e.g. breakage of crystal), or normal wear and tear;
- possible consequential damage resulting from e.g. defects, use inaccuracy or non-function of the watch;
- wear and tear of plating.

This warranty is provided by Sams Group Australia
Suite 4, 123 Clarence St, Sydney NSW 2000 Australia
Ph: 02 9290 2199 Email: repairs@samsgroup.com.au

In case of defects covered by the warranty, your watch will, at the sole option of Sams Group Australia, be repaired free of charge.

The warranty becomes void in the event of servicing or repair of the watch by any person not duly authorised by Sams Group Australia or its representatives. Should you require work under warranty, please contact Sams Group Australia directly or one of our authorised **RINGERS**  **WESTERN** stockists. The watch must be presented along with the duly completed warranty (International Guarantee), original sales receipt & contact information.

After expiry of the warranty period our dealers and service centres remain, of course, at your entire disposal for repair and maintenance of your watch against an appropriate charge.